



Alexander Defense Corp. AVDS 1790 MOTOR Parts List

#	NSN	Name	End Use Item
1	7060198	IGNITION UNIT,MANIF.	AVDS 1790 MOTOR
2	7320478	GEARSHAFT,BEVEL	AVDS 1790 MOTOR
3	8682553	GEARSHAFT,BEVEL	AVDS 1790 MOTOR
4	8682684	GEARSHAFT,BEVEL	AVDS 1790 MOTOR
5	8725146	CAP	AVDS 1790 MOTOR
6	8725289	ROCKER ARM ASSEMBLY.	AVDS 1790 MOTOR
7	8725295	ROCKER ARM ASSEMBLY.	AVDS 1790 MOTOR
8	8761084	HOUSING	AVDS 1790 MOTOR
9	10865383	.GEARSHAFT	AVDS 1790 MOTOR
10	10899003	.GEARSHAFT,BEVEL	AVDS 1790 MOTOR
11	10935542	HOUSING,COOLING FAN.	AVDS 1790 MOTOR
12	10935607	POWER TAKEOFF	AVDS 1790 MOTOR
13	10951221	CYLINDER HEAD	AVDS 1790 MOTOR
14	11683933	ROD.	AVDS 1790 MOTOR
15	11683945	SHAFT,OIL PUMP	AVDS 1790 MOTOR
16	11683951	COVER ASSEMBLY	AVDS 1790 MOTOR
17	11683957	IMPELLER:RESERVE OI.	AVDS 1790 MOTOR
18	11683958	IMPELLER:RESERVE OI.	AVDS 1790 MOTOR
19	11683965	HOUSING	AVDS 1790 MOTOR
20	11683968	SPACER ASSEMBLY	AVDS 1790 MOTOR
21	11683969	COVER ASSEMBLY	AVDS 1790 MOTOR
22	11683996	OIL PAN ASSEMBLY	AVDS 1790 MOTOR
23	11683997	HOUSING ASSEMBLY	AVDS 1790 MOTOR
24	12254203	HOUSING,SOLENOID CO	AVDS 1790 MOTOR
25	12468945	OIL PUMP ASSEMBLY,	AVDS 1790 MOTOR
26	10882763-1	PUMP ASSEMBLY	AVDS 1790 MOTOR
27	11642092-1	HOUSING	AVDS 1790 MOTOR
28	1549886-2	MOTOR	AVDS 1790 MOTOR
29	2120-01-046-1718	STATOR,ENGINE GENERATOR	AVDS 1790 MOTOR
30	2120-01-139-3722	STARTER	AVDS 1790 MOTOR
31	2130-01-024-6706	COOLER ENGINE	AVDS 1790 MOTOR
32	2520-00-011-9026	ADAPTOR	AVDS 1790 MOTOR
33	2520-00-435-4564	CLUTCH ASSEMBLY,FRI.	AVDS 1790 MOTOR
34	2520-01-136-0965	HOUSING ASSY	AVDS 1790 MOTOR
35	2520-01-162-7035	COOLER,FLUID,TRANSM	AVDS 1790 MOTOR
36	2815-00-150-7405	CYLINDER HEAD,DIESEL ENGINE	AVDS 1790 MOTOR
37	2815-00-177-9162	BASE,ACCESSORY DRIV	AVDS 1790 MOTOR

38	2815-00-394-3015	PUMP ASSY OIL	AVDS 1790 MOTOR
39	2815-00-394-7202	CONNECTION ROD.	AVDS 1790 MOTOR
40	2815-00-394-9702	CONNECTING ROD,PIST	AVDS 1790 MOTOR
41	2815-00-394-9703	NOZZLE ASSEMBLY,LUB	AVDS 1790 MOTOR
42	2815-00-394-9705	OIL PAN.	AVDS 1790 MOTOR
43	2815-00-394-9729	ENGINE BLOCK,DIESEL	AVDS 1790 MOTOR
44	2815-00-397-3316	PISTON,INTERNAL COMBUSTION ENGINE	AVDS 1790 MOTOR
45	2815-00-404-7444	FLYWHEEL,ENGINE	AVDS 1790 MOTOR
46	2815-00-410-1211	RING SET PISTON STD.	AVDS 1790 MOTOR
47	2815-00-410-1236	RING SET PISTON 0,010	AVDS 1790 MOTOR
48	2815-00-410-1248	RING SET PISTON 0,020	AVDS 1790 MOTOR
49	2815-00-410-1956	RING SET PISTON 0,030	AVDS 1790 MOTOR
50	2815-00-410-1957	RING SET PISTON 0,040	AVDS 1790 MOTOR
51	2815-00-410-1976	LEAD ASSEMBLY,ELECT	AVDS 1790 MOTOR
52	2815-00-427-0551	PISTON,INTERNAL COMBUSTION ENGINE 0,010	AVDS 1790 MOTOR
53	2815-00-427-0553	PISTON,INTERNAL COMBUSTION ENGINE 0,030	AVDS 1790 MOTOR
54	2815-00-434-6534	PISTON,INTERNAL COMBUSTION ENGINE 0,040	AVDS 1790 MOTOR
55	2815-00-434-6593	PISTON,INTERNAL COMBUSTION ENGINE 0,020	AVDS 1790 MOTOR
56	2815-00-455-9496	ADAPTOR,CAMSHAFT DR	AVDS 1790 MOTOR
57	2815-00-467-3407	PIN PISTON	AVDS 1790 MOTOR
58	2815-00-489-2575	ADAPTOR,ASSEMBLY,CR	AVDS 1790 MOTOR
59	2815-00-678-4246	GEARSHAFT	AVDS 1790 MOTOR
60	2815-00-679-8053	CAMSHAFT,ENGINE	AVDS 1790 MOTOR
61	2815-00-808-2470	FILTER,FLUID	AVDS 1790 MOTOR
62	2815-01-005-2993	HOUSING ASSEMBLY	AVDS 1790 MOTOR
63	2815-01-011-2665	ADAPTER,FLYWHEEL HOUSING	AVDS 1790 MOTOR
64	2815-01-024-9293	FLYWHEEL,ENGINE	AVDS 1790 MOTOR
65	2815-01-053-3789	CONTROL AUTOMATIC	AVDS 1790 MOTOR
66	2815-01-233-9709	CRANKSHAFT,ENGINE	AVDS 1790 MOTOR
67	2910-00-064-6262	NOZZLE,FUEL INJECTION	AVDS 1790 MOTOR
68	2910-00-808-2470	FILTER,FLUID	AVDS 1790 MOTOR
69	2910-01-011-9021	BRACKET,MOUNTING	AVDS 1790 MOTOR
70	2910-01-037-4741	FILTER,FLUID	AVDS 1790 MOTOR
71	2910-01-073-0124	PUMP,FUEL,METERING	AVDS 1790 MOTOR
72	2920-00-441-8137	GENERATOR,ENGINE ACCESSORY	AVDS 1790 MOTOR
73	2920-00-830-6660	GENERATOR,ENGINE	AVDS 1790 MOTOR
74	2920-01-018-6664	ROTOR,GENERATOR	AVDS 1790 MOTOR
75	2920-01-023-7843	PARTS KIT,TERMINAL,ENGINE IGNITION	AVDS 1790 MOTOR
76	2920-01-024-4417	STATOR,ENGINE GENERATOR	AVDS 1790 MOTOR
77	2920-01-060-0771	STUD,LINK,PIVOT	AVDS 1790 MOTOR
78	2920-01-068-3385	WIRING HARNESS,BRAN	AVDS 1790 MOTOR
79	2920-01-139-3722	STARTER,ENGINE,E	AVDS 1790 MOTOR
80	2930-00-350-9401	HOUSING,CENTRIFUGA	AVDS 1790 MOTOR
81	2930-00-679-5742	IMPELLER,FAN,AXIAL	AVDS 1790 MOTOR

82	2930-00-997-1537	SHROUD,FAN,RADIATOR	AVDS 1790 MOTOR
83	2930-01-024-6706	CORE ASSEMBLY,FLUID	AVDS 1790 MOTOR
84	2950-01-167-1699	TURBOSUPERCHARGER,E	AVDS 1790 MOTOR
85	2990-00-402-4433	BASE ASSEMBLY,	AVDS 1790 MOTOR
86	2990-01-011-2665	ADAPTER,FLYWHEEL	AVDS 1790 MOTOR
87	2990-01-136-0965	POWER TAKEOFF,	AVDS 1790 MOTOR
88	3010-00-678-4725	COUPLING,SHAFT,FLEX	AVDS 1790 MOTOR
89	3020-00-573-4568	GEARSHAFT, SPUR	AVDS 1790 MOTOR
90	3020-00-678-4238	GEAR,SPUR	AVDS 1790 MOTOR
91	3020-00-678-4239	GEARSHAFT, SPUR	AVDS 1790 MOTOR
92	3020-00-679-4972	GEAR,SPUR	AVDS 1790 MOTOR
93	3020-00-851-7176	GEARSHAFT, SPUR	AVDS 1790 MOTOR
94	3020-00-861-2389	GEAR,SPUR	AVDS 1790 MOTOR
95	3020-00-861-3829	GEAR,SPUR	AVDS 1790 MOTOR
96	3020-01-290-1298	GEAR,SPUR	AVDS 1790 MOTOR
97	3040-00-397-3319	HOUSING,MECHANICAL	AVDS 1790 MOTOR
98	3040-00-402-4422	BRACKET,EYE,	AVDS 1790 MOTOR
99	3040-00-410-1135	GEARSHAFT,SPUR .	AVDS 1790 MOTOR
100	3040-00-678-3265	SHAFT,STRAIGHT	AVDS 1790 MOTOR
101	3040-00-678-3266	HUB,BODY	AVDS 1790 MOTOR
102	3040-00-678-4236	GEARSHAFT, SPUR	AVDS 1790 MOTOR
103	3040-00-767-3200	GEARSHAFT,BEVEL	AVDS 1790 MOTOR
104	3040-00-861-1447	GEARSHAFT,SPUR	AVDS 1790 MOTOR
105	3040-01-010-3186	HOUSING,MECHANICAL	AVDS 1790 MOTOR
106	3040-01-013-1783	HOUSING,MECHANICAL	AVDS 1790 MOTOR
107	3040-01-184-4813	HOUSING,MECHANICA	AVDS 1790 MOTOR
108	3040-01-519-7683	HOUSING,MECHANICAL	AVDS 1790 MOTOR
109	3120-00-165-6010	BEARING HALF SET,SLEEVE	AVDS 1790 MOTOR
110	3120-00-165-6011	BEARING HALF SET 0,030	AVDS 1790 MOTOR
111	3120-00-165-6012	BEARING HALF SET 0,010	AVDS 1790 MOTOR
112	3120-00-410-1987	BAERING HALF SET SLEEVE 0.03	AVDS 1790 MOTOR
113	3120-00-410-1988	BAERING HALF SET SLEEVE 0.10	AVDS 1790 MOTOR
114	3120-00-423-4100	BEARING SLEEVE	AVDS 1790 MOTOR
115	3120-00-471-0314	BEARING HALF SET 0,030	AVDS 1790 MOTOR
116	3120-00-678-3229	BEARING HALF SET 0,010	AVDS 1790 MOTOR
117	3120-00-678-3230	BEARING HALF SET,SLEEVE	AVDS 1790 MOTOR
118	3120-01-018-0192	BAERING HALF SET SLEEVE STD.	AVDS 1790 MOTOR
119	3940-01-440-0283	BEAM,HOISTING	AVDS 1790 MOTOR
120	4320-01-021-3334	PUMP,ROTARY	AVDS 1790 MOTOR
121	4330-00-000-0145	FILTER ELEMENT,	AVDS 1790 MOTOR
122	4730-00-617-8626	ADAPTER AND FLANGE.	AVDS 1790 MOTOR
123	4820-00-795-1795	VALVE,CHECK	AVDS 1790 MOTOR
124	4910-00-856-4137	STAND,MAINTENANCE,A	AVDS 1790 MOTOR
125	4910-01-048-8706	SLING,ENGINE	AVDS 1790 MOTOR

126	5340-00-248-4631	COVER,ACCESS.	AVDS 1790 MOTOR
127	5340-00-498-2398	BRACKET,MOUNTING	AVDS 1790 MOTOR
128	5340-00-678-3267	PLATE,RETAINING,SEA.	AVDS 1790 MOTOR
129	5340-01-010-9086	BRACKET,MOUNTING	AVDS 1790 MOTOR
130	5365-01-011-9026	SPACER,RING	AVDS 1790 MOTOR
131	5930-01-147-7912	SWITCH,PRESSURE	AVDS 1790 MOTOR
132	5940-00-115-5001	TERMINAL,LUG	AVDS 1790 MOTOR
133	5995-00-399-5298	WIRING HARNESS,BRAN .	AVDS 1790 MOTOR
134	5995-00-507-7779	LEAD ASSEMBLY,ELECT	AVDS 1790 MOTOR
135	5995-01-245-7651	WIRING HARNESS,	AVDS 1790 MOTOR
136	5995-01-262-9527	WIRING HARNESS,BRAN	AVDS 1790 MOTOR
137	5995-01-290-1300	WIRING HARNESS,	AVDS 1790 MOTOR
138	6110-00-467-4000	REGULATOR,VOLTAGE	AVDS 1790 MOTOR
139	6150-00-118-8730	LEAD,ELECTRICAL	AVDS 1790 MOTOR
140	6150-00-410-1232	LEAD,ELECTRICAL	AVDS 1790 MOTOR
141	6150-00-423-3622	WIRING HARNESS.	AVDS 1790 MOTOR
142	6150-01-065-6631	WIRING HARNESS,	AVDS 1790 MOTOR
143	6150-01-150-9771	CABLE ASSEMBLY,POWE	AVDS 1790 MOTOR
144	6150-01-235-0411	WIRING HARNESS,	AVDS 1790 MOTOR
145	6150-01-241-9352	LEAD,ELECTRICAL.	AVDS 1790 MOTOR
146	6150-01-245-7645	CABLE ASSEMBLY,POWE	AVDS 1790 MOTOR
147	6150-01-509-3762	CABLE ASSEMBLY SET,.	AVDS 1790 MOTOR
148	6620-01-050-2086	THERMOSTAT,FLOW CON.	AVDS 1790 MOTOR
149	8145-00-856-8147	SHIPPING AND STORAG	AVDS 1790 MOTOR
150	8682737-1	ADAPTER ASSEMBLY,CR.	AVDS 1790 MOTOR
151	8761431-1	PUMP,FUEL,METERING	AVDS 1790 MOTOR