



Alexander Defense Corp. LEO 1 Parts List

#	NSN	Name	End Use Item
1	1015-12-143-0913	SHIELD SEAL	LEO 1
2	1015-12-194-0955	LIFTING CYLINDER	LEO 1
3	1015-12-195-1455	ACCUMULATOR	LEO 1
4	1015-12-308-5689	SHOOTER CONTROL UNIT	LEO 1
5	1240-12-159-7794	AUGENSCHUTZ	LEO 1
6	1240-12-191-7352	COVER	LEO 1
7	1240-12-191-7353	COVER	LEO 1
8	2520-12-146-9608	GEAR SET, SPIRAL TO	LEO 1
9	2520-12-146-9609	GEAR SET, SPIRAL TO	LEO 1
10	2520-12-146-9610	GEAR SET, SPIRAL TO	LEO 1
11	2520-12-146-9611	GEAR SET, SPIRAL TO	LEO 1
12	2520-12-146-9670	DISC CARRIER	LEO 1
13	2520-12-146-9671	PISTON	LEO 1
14	2520-12-146-9680	PUMP DRIVE GEAR	LEO 1
15	2520-12-158-9475	MANUAL ELEVATION PUMP	LEO 1
16	2520-12-178-8742	SPACER, RING	LEO 1
17	2530-00-692-9314	CAP, TRACK SHOE CENT	LEO 1
18	2530-00-692-9317	CONNECTOR, TRACK SHO	LEO 1
19	2530-12-143-0242	COOLED BRAKE DISK	LEO 1
20	2530-12-143-0254	SERVICE BRAKE PAD	LEO 1
21	2530-12-143-0269	BRAKE HIGH PRESSURE PUMP	LEO 1

22	2530-12-143-0558	TORSION BAR	LEO 1
23	2530-12-143-0559	TORSION BAR	LEO 1
24	2530-12-143-0563	CROSS-MEMBER, VEHIC	LEO 1
25	2530-12-143-0574	BEARING HOUSING,SUP	LEO 1
26	2530-12-143-0581	HUB,WHEEL,VEHICULAR	LEO 1
27	2530-12-143-0583	ARM ASSEMBLY,PIVOT,TRACK SUSPENSION	LEO 1
28	2530-12-143-0588	ARM ASSEMBLY,PIVOT,TRACK SUSPENSION	LEO 1
29	2530-12-143-0589	TENSIONER	LEO 1
30	2530-12-143-0591	SUPPORT ROLLER AXLE	LEO 1
31	2530-12-143-0601	CENTER GUIDE COMPON	LEO 1
32	2530-12-143-1025	CYLINDER ASSEMBLY,HYDRAULIC BRAKE,MASTER	LEO 1
33	2530-12-146-8901	ARM ASSEMBLY,PIVOT,TRACK SUSPENSION	LEO 1
34	2530-12-148-9220	PARKING BRAKE PAD	LEO 1
35	2530-12-148-9226	BRAKE REPAIR SET	LEO 1
36	2530-12-153-6831	TRACK SHOE	LEO 1
37	2530-12-153-6832	CENTER GUIDE, TRACK	LEO 1
38	2530-12-153-6833	CONNECTOR, END, TRA	LEO 1
39	2530-12-155-6872	SPROCKET WHEEL SEGMENT,DRIVE UNIT	LEO 1
40	2530-12-156-3709	CENTER GUIDE COMPON	LEO 1
41	2530-12-156-7551	TANK, COMBAT, FULL TR	LEO 1
42	2530-12-157-7228	GEAR TRAIN BEARING	LEO 1
43	2530-12-161-0010	CONNECTOR, END, TRA	LEO 1
44	2530-12-161-6608	SPINDLE,WHEEL,DRIVING-NONDRIVING	LEO 1
45	2530-12-165-4575	PISTON BRAKE CALIPER SERVICE	LEO 1
46	2530-12-167-5887	TRACK SHOE	LEO 1
47	2530-12-175-7545	GUIDE	LEO 1

48	2530-12-179-5716	SUPPORT ROLLER AXLE	LEO 1
49	2530-12-182-3861	SPINDLE,WHEEL,DRIVING-NONDRIVING	LEO 1
50	2530-12-199-5428	TRACK SHOE	LEO 1
51	2530-12-310-2796	TENSION DEVICE,TRACK,VEHICULAR	LEO 1
52	2530-12-312-8365	BRAKE ACCUMULATOR	LEO 1
53	2530-12-315-2023	ARM ASSEMBLY,PIVOT,TRACK SUSPENSION	LEO 1
54	2530-12-315-2677	FLANGE, BEARING, AR	LEO 1
55	2530-12-336-0302	LID, FLUID CELL, HY	LEO 1
56	2530-12-339-2226	CYLINDER ASSEMBLYH	LEO 1
57	2530-12-342-4146	CYLINDER ASSEMBLYH	LEO 1
58	2540-12-145-6305	PUMP,ROTARY	LEO 1
59	2540-12-146-2671	HOOK	LEO 1
60	2540-12-153-9075	TELESCOPIC DAMPER	LEO 1
61	2540-12-156-5169	SHOCK ABSORBER LOCK CONNECTION	LEO 1
62	2590-12-144-6067	SCHLAUCHLEITUNG	LEO 1
63	2590-12-145-6366	RECOVERER	LEO 1
64	2590-12-146-9233	SCHWENKTELLER, MUNI	LEO 1
65	2590-12-167-9324	BOM DONDURME DISLI KUTUSU (BOS)	LEO 1
66	2590-12-325-5383	COOLER, CHARGE - AIR	LEO 1
67	2590-12-325-5384	COOLER, CHARGE - AIR	LEO 1
68	2590-12-336-0303	TANK, OIL, HYDRAULIC	LEO 1
69	2815-12-142-8635	CONNECTING ROD,PIST	LEO 1
70	2815-12-142-8639	SCREW	LEO 1
71	2815-12-142-8721	INSERT	LEO 1
72	2815-12-142-8722	OIL CONTAINER	LEO 1
73	2815-12-142-8749	FLANGE, CRANKCASE	LEO 1

74	2815-12-142-8845	OIL PUMP ASSEMBLY,E	LEO 1
75	2815-12-142-8847	PUMP, OIL	LEO 1
76	2815-12-142-8860	MANIFOLD	LEO 1
77	2815-12-142-8885	BEARING,SLEEVE	LEO 1
78	2815-12-142-8890	BEARING,SLEEVE	LEO 1
79	2815-12-142-8894	BEARING,SLEEVE	LEO 1
80	2815-12-154-2662	RING SET,PISTON	LEO 1
81	2815-12-156-2661	TAPE,TEXTILE	LEO 1
82	2815-12-157-6998	PISTON,INTERNAL COM	LEO 1
83	2815-12-158-7417	CYLINDER SLEEVE	LEO 1
84	2815-12-158-7451	PISTON,INTERNAL COM	LEO 1
85	2815-12-167-0765	RING	LEO 1
86	2815-12-176-4754	BRACKET, SEAL RING	LEO 1
87	2815-12-198-9192	RING,CYLINDER LINER	LEO 1
88	2815-12-198-9193	RING,CYLINDER LINER	LEO 1
89	2815-12-199-2996	PIN,PISTON	LEO 1
90	2910-12-128-8594	FILTER CARTRIDGE, FLOW	LEO 1
91	2910-12-143-0203	PUMP, FUEL (BOSCH)	LEO 1
92	2910-12-172-1331	ADAPTER	LEO 1
93	2910-12-172-1332	ADAPTER	LEO 1
94	2910-12-181-1246	BUCHSE	LEO 1
95	2910-12-195-1310	YAKIT POMPASI	LEO 1
96	2920-00-692-9317	CONNECTOR,TRACK SHO	LEO 1
97	2920-00-795-6627	GENERATOR ENGINE AC	LEO 1
98	2920-12-142-8180	GENERATOR,ENGINE AC	LEO 1
99	2920-12-142-8542	STARTER,ENGINE,ELEC	LEO 1

100	2920-12-142-8551	GENERATOR,ENGINE AC	LEO 1
101	2920-12-142-8565	RECTIFIER (SIEMENS)	LEO 1
102	2920-12-143-1960	VOLTAGE REGULATOR	LEO 1
103	2920-12-197-4265	EINPURANTRIEB	LEO 1
104	2930-12-143-1042	WATER SOUND	LEO 1
105	2930-12-143-1043	WATER CUT PROBE 20 LTS	LEO 1
106	2930-12-146-9499	SUPPORT RING	LEO 1
107	2930-12-159-0338	SCOOP TUB CARRIER	LEO 1
108	2930-12-198-5385	COOLER,LUBRICATING	LEO 1
109	2930-12-199-4424	RADIATOR ENGINE	LEO 1
110	2930-12-326-5840	WATER PUMP MOTOR	LEO 1
111	2940-12-142-8182	ENGINE OIL FILTER	LEO 1
112	2940-12-302-4020	HAVA EMİŞ MOTORU	LEO 1
113	2940-12-333-6903	HAVA EMİŞ MOTORU	LEO 1
114	2940-12-343-9565	AIR FILTER CARTRIDGE	LEO 1
115	2990-12-150-8563	STARTER,ENGINE, ELEC.	LEO 1
116	3020-12-146-9580	GEAR SET,SPUR,MATCHED	LEO 1
117	3020-12-146-9657	GEAR, INTERNAL AND	LEO 1
118	3020-12-153-7137	SPROCKET WHEEL	LEO 1
119	3020-12-158-7060	SPEEDOMETER WORM	LEO 1
120	3020-12-189-2050	GUARD,MECHANICAL DR	LEO 1
121	3040-12-164-5360	SPEEDO SHAFT	LEO 1
122	3040-12-176-5806	HEAD,LINEAR ACTUATI	LEO 1
123	3040-12-176-7810	CAP,LINEAR ACTUATIN	LEO 1
124	3040-12-176-8835	AXLE,SHOULDERED	LEO 1
125	3040-12-189-9009	ZYLINDERBAUGRUPPE	LEO 1

126	3040-12-198-8402	WINKELHEBEL	LEO 1
127	3120-12-142-8738	BEARING HALF SET,SL	LEO 1
128	3120-12-142-8739	BEARING HALF SET,SL	LEO 1
129	3120-12-142-8740	BEARING HALF SET,SL	LEO 1
130	3120-12-142-8741	BEARING HALF SET,SL	LEO 1
131	3120-12-142-8742	BEARING HALF SET,SL	LEO 1
132	3120-12-142-8743	BEARING HALF SET,SL	LEO 1
133	3120-12-142-8744	BEARING HALF SET,SL	LEO 1
134	3120-12-142-8745	BEARING HALF SET,SL	LEO 1
135	3120-12-166-9977	BEARING HALF SET,SL	LEO 1
136	3120-12-166-9978	BEARING HALF SET,SL	LEO 1
137	3120-12-166-9979	BEARING HALF SET,SL	LEO 1
138	3120-12-166-9980	BEARING HALF SET,SL	LEO 1
139	3120-12-166-9981	BEARING HALF SET,SL	LEO 1
140	3120-12-166-9982	BEARING HALF SET,SL	LEO 1
141	3120-12-166-9983	BEARING HALF SET,SL	LEO 1
142	3120-12-166-9984	BEARING HALF SET,SL	LEO 1
143	3120-12-166-9985	BEARING HALF SET,SL	LEO 1
144	3120-12-166-9986	BEARING HALF SET,SL	LEO 1
145	3120-12-166-9987	BEARING HALF SET,SL	LEO 1
146	3120-12-166-9988	BEARING HALF SET,SL	LEO 1
147	3120-12-166-9989	BEARING HALF SET,SL	LEO 1
148	3120-12-166-9990	BEARING HALF SET,SL	LEO 1
149	3120-12-166-9991	BEARING HALF SET,SL	LEO 1
150	3120-12-166-9992	BEARING HALF SET,SL	LEO 1
151	3120-12-198-6918	BEARING,SLEEVE	LEO 1

152	3120-12-309-6249	BEARING HALF SET,SL	LEO 1
153	3120-12-309-6250	BEARING HALF SET,SL	LEO 1
154	3120-12-309-6251	BEARING HALF SET,SL	LEO 1
155	3120-12-309-6252	BEARING HALF SET,SL	LEO 1
156	3120-12-309-6254	BEARING HALF SET,SL	LEO 1
157	3120-12-309-6255	BEARING HALF SET,SL	LEO 1
158	3120-12-309-6256	BEARING HALF SET,SL	LEO 1
159	3120-12-309-6257	BEARING HALF SET,SL	LEO 1
160	3120-12-309-6258	BEARING HALF SET,SL	LEO 1
161	3120-12-309-6259	BEARING HALF SET,SL	LEO 1
162	3120-12-309-6260	BEARING HALF SET,SL	LEO 1
163	3810-12-341-1493	CRANE,TRUCK MOUNTED	LEO 1
164	3940-12-190-6051	DRIFTPIN	LEO 1
165	3940-12-190-6062	BEAM,HOISTING	LEO 1
166	3940-12-191-4956	SLING,BEAM TYPE	LEO 1
167	3940-12-352-9291	ADAPTER,HOISTING	LEO 1
168	3940-12-353-3469	TRAEGER, HEBE	LEO 1
169	3940-12-362-1161	ADAPTER,HOISTING	LEO 1
170	3950-12-191-4959	BOOM,HOIST SUPPORT	LEO 1
171	3990-12-366-1685	BINDER,LOAD	LEO 1
172	4320-12-145-9090	PLATE,CAPACITOR	LEO 1
173	4320-12-150-9468	RAM,HYDRAULIC	LEO 1
174	4320-12-151-5870	RAM,HYDRAULIC	LEO 1
175	4320-12-156-8975	PUMP,HYDRAULIC RAM,	LEO 1
176	4320-12-176-4508	PUMP,HYDRAULIC RAM,	LEO 1
177	4320-12-176-7458	PARTS KIT,RECIPROCA	LEO 1

178	4320-12-178-7742	BILGE PUMP	LEO 1
179	4320-12-178-7743	BILGE PUMP	LEO 1
180	4320-12-189-8603	PUMP,HYDRAULIC RAM,	LEO 1
181	4320-12-199-9155	MANUAL PUMP PRESSURIZATION SYSTEM	LEO 1
182	4320-12-326-3732	PUMP,HYDRAULIC RAM,	LEO 1
183	4330-12-191-7186	STRAINER ASSEMBLY,D	LEO 1
184	4710-12-157-0332	HOUSING	LEO 1
185	4710-12-190-7127	ROHR, METALL	LEO 1
186	4720-12-143-5951	SCHLAUCH, NICHTMETA	LEO 1
187	4720-12-152-0484	HOSE ASSEMBLY,NONME	LEO 1
188	4720-12-185-5231	HOSE ASSEMBLY,NONME	LEO 1
189	4720-12-187-5432	HOSE ASSEMBLY,NONME	LEO 1
190	4720-12-320-3804	HOSE ASSEMBLY,NONME	LEO 1
191	4720-12-320-4740	HOSE ASSEMBLY,NONME	LEO 1
192	4720-12-320-6036	HOSE ASSEMBLY,NONME	LEO 1
193	4720-12-320-7617	HOSE ASSEMBLY,NONME	LEO 1
194	4720-12-324-2706	HOSE ASSEMBLY,NONME	LEO 1
195	4720-12-366-2732	HOSE ASSEMBLY,NONME	LEO 1
196	4730-12-143-0234	MOTOR COUPLING/WATER HALF (FEMALE)	LEO 1
197	4730-12-151-9548	TEE,TUBE TO BOSS	LEO 1
198	4730-12-152-3226	COUPLING HALF,SELF-	LEO 1
199	4730-12-153-7615	COUPLING HALF/WATER MOTOR (MALE)	LEO 1
200	4730-12-189-1421	COUPLING HALF,QUICK	LEO 1
201	4730-12-320-6445	COUPLING HALF,QUICK	LEO 1
202	4730-12-326-3228	ADAPTER,STRAIGHT,TU	LEO 1
203	4730-12-328-6155	ADAPTER,STRAIGHT,TU	LEO 1

204	4810-12-164-5608	VALVE ASSEMBLY, GLO	LEO 1
205	4820-12-313-7752	VALVE,SAFETY RELIEF	LEO 1
206	4910-12-144-6060	LASTENGESCHIRR, VER	LEO 1
207	4910-12-145-0625	PRUEFGERAET, GENERA	LEO 1
208	4910-12-145-6795	STAENDER, FAHRZEUG	LEO 1
209	4910-12-145-6796	STAENDER, FAHRZEUG	LEO 1
210	4910-12-145-6797	STAENDER, FAHRZEUG	LEO 1
211	4910-12-145-6798	STAENDER, FAHRZEUG	LEO 1
212	4910-12-149-7906	ADAPTER,CYLINDER CO	LEO 1
213	4910-12-149-7907	ADAPTER,CYLINDER CO	LEO 1
214	4910-12-151-5983	TESTER,PRESSURE EQU	LEO 1
215	4910-12-151-5985	ADAPTER	LEO 1
216	4910-12-153-4951	STAND,MAINTENANCE,A	LEO 1
217	4910-12-158-5275	TEST SET,GENERATOR	LEO 1
218	4910-12-189-1445	SCHALTKASTEN,ELEKTR	LEO 1
219	4910-12-189-1573	SCHUTZGITTER	LEO 1
220	4910-12-189-1731	FLANGE	LEO 1
221	4910-12-189-2228	HOUSTING LINK	LEO 1
222	4910-12-189-4151	TESTER, ELECTRICAL	LEO 1
223	4910-12-190-1159	TESTER, ELECTRICAL	LEO 1
224	4910-12-190-1160	TESTER,BRAKE,MOTOR	LEO 1
225	4910-12-190-1161	ABLASZVORRICHTUNG	LEO 1
226	4910-12-190-5810	REINIGUNGSGERAET	LEO 1
227	4910-12-191-2099	ADAPTER	LEO 1
228	4910-12-199-2484	CONSOLE, IC ENGINE	LEO 1
229	4910-12-199-3679	CONSOLE, IC ENGINE	LEO 1

230	4910-12-313-0751	STAENDER, MONTAGE	LEO 1
231	4910-12-336-0718	TANK, KRAFTSTOFF, P	LEO 1
232	4910-12-346-5491	TESTER, ELECTRICAL	LEO 1
233	4910-12-346-5492	TESTER, ELECTRICAL	LEO 1
234	4910-12-356-4036	LASTENGESCHIRR, VER	LEO 1
235	4910-12-357-2013	LASTENGESCHIRR, VER	LEO 1
236	4910-12-365-5742	TEST SET, HYDRAULIC	LEO 1
237	4910-12-366-8812	STAND, MAINTENANCE, A	LEO 1
238	4910-KK-015-0015	WASHER, FLAT	LEO 1
239	4930-12-192-3973	ABFUELLPUMPE, ELEKT	LEO 1
240	4931-12-186-7969	PRUEFGERAET, GLEICH	LEO 1
241	4931-12-188-0032	TEST SET, FIRE CONTR	LEO 1
242	4931-12-191-2726	SPANNVORRICHTUNG	LEO 1
243	4931-12-191-3922	SPANNVORRICHTUNG	LEO 1
244	4931-12-191-3923	ABSTIMMWERKZEUG	LEO 1
245	4931-12-300-2601	BEHAELTER, PERISKOP	LEO 1
246	4931-12-306-7411	TEST SET, FIRE CONTR	LEO 1
247	4931-12-311-0718	TEST SET, FIRE CONTR	LEO 1
248	4933-12-189-6104	JUSTIERVORRICHTUNG	LEO 1
249	4933-12-190-7837	EIN- UND AUSBAUVORR	LEO 1
250	4933-12-190-9096	JUSTIERVORRICHTUNG	LEO 1
251	4933-12-190-9097	EIN- UND AUSBAUVORR	LEO 1
252	4933-12-190-9232	TRAEGER, HEBE, -BOD	LEO 1
253	4933-12-191-6302	PRUEFGERAET	LEO 1
254	4933-12-191-6304	SICHERUNGSELEMENT	LEO 1
255	4933-12-191-6305	SICHERUNGSELEMENT	LEO 1

256	4933-12-191-6306	SICHERUNGSELEMENT	LEO 1
257	4933-12-191-6307	PRUEFGERAET, HYDRAU	LEO 1
258	4933-12-191-6308	PRUEFGERAET, STROMK	LEO 1
259	4933-12-192-9837	VERSCHLUSZTEILSATZ	LEO 1
260	4933-12-315-9249	UEBERWACHUNGSGERAET	LEO 1
261	4933-12-320-2448	INSTANDSETZUNGSHALT	LEO 1
262	4933-12-340-1884	VERBINDUNGSSTUECK	LEO 1
263	4933-12-353-5968	PRUEFGERAET, WAFFEN	LEO 1
264	4933-27-056-0195	KILAVUZ, MERKEZLEME, NİŞAN HATTI AYAR SETİ İÇİN	LEO 1
265	4940-12-126-3762	WANNE, WERKSTATT	LEO 1
266	4940-12-191-7185	PRESS, HYDRAULIC, POR	LEO 1
267	4940-12-198-7587	CASE, TEST SET	LEO 1
268	4940-KK-028-2765	LOAD	LEO 1
269	4940-KK-028-2768	RESISTOR, VARIABLE, WIRE WOUND, NONPRECISION	LEO 1
270	5120-12-133-6180	GRIFF, VERLAENGERUN	LEO 1
271	5120-12-133-8165	PLIERS, RETAINING RI	LEO 1
272	5120-12-139-3052	SCHLUESSEL	LEO 1
273	5120-12-143-0747	MONTING TOOL, TRACK	LEO 1
275	5120-12-143-0748	MONTING TOOL, TRACK	LEO 1
277	5120-12-143-0775	ABHEBEVORRICHTUNG	LEO 1
279	5120-12-143-1069	SCHLUESSEL	LEO 1
280	5120-12-143-9801	TRAGARMHEBER, LAUFR	LEO 1
281	5120-12-143-9802	SCHLUESSEL	LEO 1
282	5120-12-143-9803	DRUCKHEBEL, BREMSKO	LEO 1
283	5120-12-144-2095	DURCHDREHVORRICHTUN	LEO 1
284	5120-12-144-2098	DURCHDREHVORRICHTUN	LEO 1

285	5120-12-144-5013	EINSATZ, SCHRAUBEND	LEO 1
286	5120-12-144-6087	SPERRVORRICHTUNG	LEO 1
287	5120-12-144-6088	HALTEVORRICHTUNG	LEO 1
288	5120-12-144-6089	PULLER,MECHANICAL	LEO 1
289	5120-12-144-6090	EINPRESZVORRICHTUNG	LEO 1
290	5120-12-144-6091	SCHLUESSELEINSATZ	LEO 1
291	5120-12-144-6292	WRENCH,SPANNER	LEO 1
292	5120-12-144-6293	SCHLUESSEL, MITNEHM	LEO 1
293	5120-12-144-6294	MONTAGEBUCHSE, TRAG	LEO 1
294	5120-12-144-6295	MONTAGESTEMPEL,TRAG	LEO 1
295	5120-12-144-6296	MONTAGESTEMPEL,TRAG	LEO 1
296	5120-12-144-6297	PUNCH	LEO 1
297	5120-12-144-6298	HEBEL,SPANN	LEO 1
298	5120-12-145-1013	PUNCH	LEO 1
299	5120-12-145-1014	MONTAGEVORRICHTUNG	LEO 1
300	5120-12-145-8056	AUFPRESZVORRICHTUNG	LEO 1
301	5120-12-147-9803	EIN- UND AUSBAUVORR	LEO 1
302	5120-12-148-5396	SCHRAUBENDREHER, IN	LEO 1
303	5120-12-149-7908	ANZIEHVORRICHTUNG	LEO 1
304	5120-12-149-8022	UEBERLAUFROHR, BEHA	LEO 1
305	5120-12-150-6113	ADAPTER,TORQUE WREN	LEO 1
306	5120-12-150-9143	MONTAGEHAKEN, KOMPE	LEO 1
307	5120-12-151-5394	MONTAGEVORRICHTUNG	LEO 1
308	5120-12-151-5396	ABZIEHER, HYDRAULIS	LEO 1
309	5120-12-151-5400	PIN	LEO 1
310	5120-12-151-5869	MONTAGEVORRICHTUNG	LEO 1

311	5120-12-151-6515	GEWINDEDORN	LEO 1
312	5120-12-152-7949	SPANNER WRENCH	LEO 1
313	5120-12-153-5156	ABZIEHER, HYDRAULIS	LEO 1
314	5120-12-153-5157	PULLER,MECHANICAL	LEO 1
315	5120-12-156-5198	FUEHRUNGSSTANGE,SEI	LEO 1
316	5120-12-176-6020	BAR,SOCKET WRENCH H	LEO 1
317	5120-12-176-6022	ELEVATING BLOCK,JAC	LEO 1
318	5120-12-176-6023	RING,SCHUTZ-	LEO 1
319	5120-12-176-6024	WRENCH,SPANNER	LEO 1
320	5120-12-176-7228	WRENCH	LEO 1
321	5120-12-176-7811	SCREWDRIVER,FLAT TI	LEO 1
322	5120-12-180-4828	WRENCH	LEO 1
323	5120-12-184-5026	VERLAENGERUNG	LEO 1
324	5120-12-189-7272	WRENCH,BOX	LEO 1
325	5120-12-189-7506	SCHLUESSEL,SPEZIAL-	LEO 1
326	5120-12-189-8175	ADAPTER,TORQUE WREN	LEO 1
327	5120-12-189-8527	WRENCH,OPEN END	LEO 1
328	5120-12-189-8988	WRENCH	LEO 1
329	5120-12-189-8989	MONTAGESTAB	LEO 1
330	5120-12-190-0403	ADAPTER,TORQUE WREN	LEO 1
331	5120-12-190-2866	INSERTER,SEAL	LEO 1
332	5120-12-190-2867	DRIFTPIN	LEO 1
333	5120-12-190-3133	STEMMER	LEO 1
334	5120-12-190-3348	ABZIEHVORRICHTUNG	LEO 1
335	5120-12-190-4898	MOUNTING DEVICE	LEO 1
336	5120-12-190-6053	BRACKET	LEO 1

337	5120-12-190-6054	BRACKET	LEO 1
338	5120-12-190-6055	WRENCH COMPONENT	LEO 1
339	5120-12-190-6056	WRENCH	LEO 1
340	5120-12-190-6057	EINPRESZWERKZEUG	LEO 1
341	5120-12-190-6059	BEAM,HOISTING	LEO 1
342	5120-12-190-6071	FIXTURE	LEO 1
343	5120-12-190-6074	GLEITHAMMER	LEO 1
344	5120-12-190-6689	WRENCH,SOCKET	LEO 1
345	5120-12-190-6772	PUNCH,ALIGNING	LEO 1
346	5120-12-190-7328	REPLACING TOOL, BAR	LEO 1
347	5120-12-190-7331	SPANNVORRICHTUNG	LEO 1
348	5120-12-190-7332	EINBAUVORRICHTUNG	LEO 1
349	5120-12-190-7388	GEWINDEBOLZEN	LEO 1
350	5120-12-190-7389	GEWINDEBOLZEN	LEO 1
351	5120-12-190-7390	GEWINDEBOLZEN	LEO 1
352	5120-12-190-7391	GEWINDEBOLZEN	LEO 1
353	5120-12-190-7392	GEWINDEBOLZEN	LEO 1
354	5120-12-190-8431	ABZIEHVORRICHTUNG	LEO 1
355	5120-12-190-8432	PULLER ATTACHMENT,M	LEO 1
356	5120-12-190-8433	PULLER ATTACHMENT,M	LEO 1
357	5120-12-191-4639	WRENCH,SPANNER	LEO 1
358	5120-12-191-4895	PUNCH,ALIGNING	LEO 1
359	5120-12-191-4896	FANGSTIFT	LEO 1
360	5120-12-191-5203	ABDRUECKVORRICHTUNG	LEO 1
361	5120-12-191-6678	STECKSCHLUESSELEINS	LEO 1
362	5120-12-191-6681	WRENCH,SPANNER	LEO 1

363	5120-12-191-6684	WRENCH	LEO 1
364	5120-12-191-6685	AUSZIEHVORRICHTUNG	LEO 1
365	5120-12-191-6689	EINBAUWERKZEUG	LEO 1
366	5120-12-191-7859	SOCKET,WRENCH,FACE	LEO 1
367	5120-12-192-3327	WRENCH,OPEN END	LEO 1
368	5120-12-192-5980	EINPRESZWERKZEUG	LEO 1
369	5120-12-300-3075	SCREWDRIVER ATTACHM	LEO 1
370	5120-12-300-9688	LEVER, MOUNTING	LEO 1
371	5120-12-303-4484	WRENCH,SPANNER	LEO 1
372	5120-12-314-1016	SOCKET,SOCKET WRENC	LEO 1
373	5120-12-324-1676	INDENTATION TOOL, M	LEO 1
374	5120-12-324-2369	SOCKET,WRENCH,FACE	LEO 1
375	5120-12-326-0068	STEP PLATE,MECHANIC	LEO 1
376	5120-12-326-0069	PULLER,MECHANICAL	LEO 1
377	5120-12-326-0071	STEP PLATE,MECHANIC	LEO 1
378	5120-12-326-0074	STEP PLATE,MECHANIC	LEO 1
379	5120-12-326-0075	WRENCH,SPANNER	LEO 1
380	5120-12-332-1741	SOCKET,SOCKET WRENC	LEO 1
381	5120-12-349-6638	SCHLUESSEL, MAUL	LEO 1
382	5136-12-300-9840	DIE,THREAD CUTTING	LEO 1
383	5140-12-151-5931	CHEST,TOOL KIT	LEO 1
384	5140-12-156-1348	CHEST,TOOL KIT	LEO 1
385	5140-12-156-1349	CHEST,TOOL KIT	LEO 1
386	5140-27-056-0196	CHEST,TOOL KIT	LEO 1
387	5210-12-120-5146	STELLWINKEL, GLEITE	LEO 1
388	5210-12-151-0416	LEHRE, EINSTELL	LEO 1

389	5210-12-151-0417	LEHRE, EINSTELL (0,8MM)	LEO 1
390	5210-12-164-8989	EINSTELLVORRICHTUNG	LEO 1
391	5210-12-187-1738	LEHRE, EINSTELL-	LEO 1
392	5210-12-189-1226	EINSTELLVORRICHTUNG	LEO 1
393	5210-12-190-6050	DRIFTPIN	LEO 1
394	5210-12-190-8155	EINSTELLVORRICHTUN	LEO 1
395	5210-12-315-1148	GAGE,THICKNESS	LEO 1
396	5210-12-319-3974	BLADE,THICKNESS GAG	LEO 1
397	5210-12-319-3975	BLADE,THICKNESS GAG	LEO 1
398	5210-12-319-4696	BLADE,THICKNESS GAG	LEO 1
399	5210-12-320-2449	GAGE STICK,PETROLEU	LEO 1
400	5210-12-320-2450	GAGE STICK,PETROLEU	LEO 1
401	5210-12-379-5213	HALTER, FUEHLERLEHR	LEO 1
402	5220-12-143-1070	ASTA DI MISURAZIONE	LEO 1
403	5220-12-158-3323	HUELLE,SCHUTZ-	LEO 1
404	5220-12-190-6687	EHRE, PRUEF-	LEO 1
405	5220-12-190-6688	LEHRE, PRUEF-	LEO 1
406	5305-12-190-2179	SCREW,EXTERNALLY	LEO 1
407	5305-12-190-2180	CREW,CAP,HEXAGON H	LEO 1
408	5305-12-190-9252	THUMBSCREW	LEO 1
409	5305-12-310-2594	SETSCREW	LEO 1
410	5306-12-354-9397	SCHRAUBE, AUGENKOPF	LEO 1
411	5307-12-150-8328	SCHRAUBE	LEO 1
412	5315-12-173-7361	PIN	LEO 1
413	5315-12-181-1754	FEDERTELLER	LEO 1
414	5340-12-143-0449	DAMPING BEARING	LEO 1

415	5340-12-143-0788	RUBBER BEARING PANEL AND BILGE PUMP	LEO 1
416	5340-12-181-1704	HANDLE, MANUAL CONTR	LEO 1
417	5340-12-190-6690	COVER,ACCESS	LEO 1
418	5340-12-190-6691	COVER,ACCESS	LEO 1
419	5340-12-190-6692	COVER,ACCESS	LEO 1
420	5340-12-190-6693	COVER,ACCESS	LEO 1
421	5342-12-194-7755	COUPLING, CLAMP, GROO	LEO 1
422	5360-12-142-8650	FEDER	LEO 1
423	5360-12-142-8652	FEDER	LEO 1
424	5360-12-143-0598	EVOLUTE SPRING	LEO 1
425	5360-12-143-0599	EVOLUTE SPRING	LEO 1
426	5365-12-191-0973	SPACER,PLATE	LEO 1
427	5855-12-185-9752	COVER	LEO 1
428	5855-12-185-9753	COVER	LEO 1
429	5855-12-185-9754	COVER	LEO 1
430	5855-12-185-9755	COVER	LEO 1
431	5855-12-190-2094	COVER	LEO 1
432	5930-12-122-4563	STARTER SWITCH	LEO 1
433	5930-12-143-0275	BRAKE PRESSURE BULB	LEO 1
434	5930-12-143-1033	ACCUMULATOR PRESSURE BULB	LEO 1
435	5930-12-166-0796	SELECTOR SWITCH INSTRUMENT PANEL	LEO 1
436	5930-12-195-6935	BRAKE PRESSURE SWITCH	LEO 1
437	5930-12-349-6051	SWITCH , PRESSURE	LEO 1
438	5940-12-143-0475	CONNECTION BOX	LEO 1
439	5945-12-143-0535	MASS RELAY	LEO 1
440	5945-12-152-1227	RELAY BOX	LEO 1

441	5945-12-173-0299	INSTRUMENT PANEL RELAY	LEO 1
442	5945-12-178-6370	FLANGE	LEO 1
443	5977-12-149-8627	BRUSH ELECTRIC MOTOR	LEO 1
444	6105-12-145-5774	PLATE,CAPACITOR	LEO 1
445	6105-12-148-2960	MOTOR,DIRECT CURRENT	LEO 1
446	6105-12-152-1218	MOTOR,DIRECT CURRENT	LEO 1
447	6105-12-158-1674	MOTOR, NBC	LEO 1
448	6105-12-171-7389	GASKET	LEO 1
449	6105-12-186-8105	PACKING PREFORMED	LEO 1
450	6105-12-191-4781	HOUSING	LEO 1
451	6110-12-307-4809	MAIN RELAY BOX	LEO 1
452	6110-12-308-2164	CENTRAL ELECTRONIC UNIT (UET)	LEO 1
453	6140-12-190-9027	BATTERY	LEO 1
454	6150-12-150-7839	CABLE ASSEMBLY,SPEC	LEO 1
455	6150-12-186-8910	CABLE ASSEMBLY,SPEC	LEO 1
456	6150-12-187-0454	WIRING HARNESS,BRAN	LEO 1
457	6150-12-196-5981	CABLE ASSEMBLY,SPEC	LEO 1
458	6150-12-321-0759	CABLE ASSEMBLY,SPEC	LEO 1
459	6150-12-321-0760	CABLE ASSEMBLY,SPEC	LEO 1
460	6150-12-321-0761	CABLE ASSEMBLY,SPEC	LEO 1
461	6150-12-321-0762	CABLE ASSEMBLY,SPEC	LEO 1
462	6150-12-321-0763	CABLE ASSEMBLY,SPEC	LEO 1
463	6150-12-321-0764	LEAD,ELECTRICAL	LEO 1
464	6150-12-321-0765	LEAD,ELECTRICAL	LEO 1
465	6150-12-321-0766	CABLE ASSEMBLY,SPEC	LEO 1
466	6150-12-321-0767	CABLE ASSEMBLY,SPEC	LEO 1

467	6150-12-321-0768	CABLE ASSEMBLY,SPEC	LEO 1
468	6150-12-321-0769	CABLE ASSEMBLY,SPEC	LEO 1
469	6150-12-324-7406	CABLE ASSEMBLY-SWIT	LEO 1
470	6210-12-189-5020	LAMP, RED INDICATOR	LEO 1
471	6210-12-193-9447	LIGHT,INDICATOR	LEO 1
472	6230-12-191-7709	LIGHT,EXTENSION	LEO 1
473	6230-12-191-7710	LIGHT,EXTENSION	LEO 1
474	6515-12-236-0002	SYRINGE,AIR,MEDICAL	LEO 1
475	6625-12-330-1502	TEST SET,THERMOSTAT	LEO 1
476	6625-KK-021-5180	CALCULATOR,ELECTRONIC	LEO 1
477	6640-12-137-2580	REINIGUNGSTUCH, LIN	LEO 1
478	6650-KK-042-9786	FERNGLAS KIT	LEO 1
479	6680-12-127-4194	ZAehler, UMDREHUNGS	LEO 1
480	6680-12-143-0273	ACTUATOR, LIQUID	LEO 1
481	6680-12-143-0274	LIQUID SWITCH	LEO 1
482	6680-12-143-1031	TACHOMETER	LEO 1
483	6685-12-142-8598	MOTOR ROTATION SENSOR	LEO 1
484	6685-12-143-1024	TEMPERATURE INDICATOR	LEO 1
485	6685-12-330-4945	THERMOMETER,SELF-IN	LEO 1
486	7010-12-371-0691	COMPUTER SYSTEM,DIG	LEO 1
487	8115-12-189-1565	BOX,SHIPPING	LEO 1
488	8115-12-189-1566	BOX,SHIPPING	LEO 1
489	8115-12-189-1567	BOX,SHIPPING	LEO 1
490	8115-12-189-2031	BOX,SHIPPING	LEO 1
491	8115-12-189-2040	BOX,SHIPPING	LEO 1
492	8115-12-189-2041	BOX,SHIPPING	LEO 1

493	8115-12-189-2042	BOX,SHIPPING	LEO 1
494	8115-12-189-2047	BOX,SHIPPING	LEO 1
495	8115-12-189-2048	BOX,SHIPPING	LEO 1
496	8115-12-189-2049	BOX,SHIPPING	LEO 1
497	8115-12-199-4641	BOX,SHIPPING	LEO 1
498	8115-12-326-0241	BOX,SHIPPING	LEO 1
499	8145-12-191-8068	SHIPPING AND STORAG	LEO 1
500	8145-12-191-8069	SHIPPING AND STORAG	LEO 1
501	8145-12-191-8072	SHIPPING AND STORAG	LEO 1
502	8145-12-191-8073	SHIPPING AND STORAG	LEO 1
503	8145-12-191-8074	SHIPPING AND STORAG	LEO 1
504	8145-12-320-5690	SHIPPING AND STORAG	LEO 1
505	838-010-11-14	DECKEL (FILTER UNIT)	LEO 1