



Alexander Defense Corp. LEO 2 Parts List

#	NSN	Name	End Use Item
1	869094005	PUMP	LEO 2
2	7000800723	TURBO FLANGE	LEO 2
3	8330700821	REGULIERHE	LEO 2
4	8331504733	CABLE ASSY SPECIAL	LEO 2
5	8380770212	GEAR	LEO 2
6	8690740251	GEAR SPUR	LEO 2
7	8691510310	GEAR SPUR	LEO 2
8	1015-12-177-2247	INSERT	LEO 2
9	1015-12-177-3090	KABEL, SPEZIAL-, AN	LEO 2
10	1015-12-178-8252	HOEHENRICHTZYLINDER	LEO 2
11	1015-12-192-6805	SLIP RING TRANSMITTER	LEO 2
12	1873-101000.001.0	HEBEL ARM	LEO 2
13	2500-12-310-2796	TENSION DEVICE, TRACK, VEHICULAR	LEO 2
14	2520-12-178-7743	PUMP, ROTARY	LEO 2
15	2520-12-188-8346	ACCUMULATOR, HYDRAULIC	LEO 2
16	2530-12-173-4865	ENTLUEFTUNGSSCHRAUB / VALVE	LEO 2
17	2530-12-175-7542	TRACK SHOE, VEHICULAR	LEO 2
18	2530-12-175-7544	CONNECTOR, TOP	LEO 2
19	2530-12-175-7545	CONNECTOR BASE, CENTER	LEO 2
20	2530-12-175-8488	NABE, RAD, FAHRZEUG	LEO 2
21	2530-12-175-8491	TORSION BAR, SUSPENSION	LEO 2
22	2530-12-175-8492	TORSION BAR, SUSPENSION	LEO 2
23	2530-12-175-8495	ARM ASSEMBLY, PIVOT, TRACK SUSPENSION	LEO 2
24	2530-12-175-8497	ARM ASSEMBLY, PIVOT, TRACK SUSPENSION	LEO 2
25	2530-12-175-8498	ARM ASSEMBLY, PIVOT, TRACK SUSPENSION	LEO 2
26	2530-12-175-8499	TENSION DEVICE, TRACK, VEHICULAR LEFT	LEO 2
27	2530-12-175-8500	TENSION DEVICE, TRACK, VEHICULAR RIGHT	LEO 2
28	2530-12-175-8501	STUETZROLLE, GLEISK	LEO 2
29	2530-12-177-2940	HYDRAULIC UNIT	LEO 2
30	2530-12-177-2941	HYDRAULIC UNIT	LEO 2
31	2530-12-178-1186	SUPPORT ROLLER AXLE	LEO 2
32	2530-12-178-7177	SPROCKET WHEEL	LEO 2
33	2530-12-178-7742	PUMP, ROTARY	LEO 2
34	2530-12-179-0451	BRAKE, SEGMENTED ROTOR	LEO 2
35	2530-12-184-6975	CONNECTOR, END, TRA	LEO 2
36	2530-12-184-9978	ACCUMULATOR, HYDRAULIC	LEO 2

37	2530-12-187-7614	LABYRINTHRING	LEO 2
38	2530-12-188-8504	BREMSRING	LEO 2
39	2530-12-189-0535	RING	LEO 2
40	2530-12-189-0536	PLATTE	LEO 2
41	2530-12-189-0538	VEHICLER BRAKE	LEO 2
42	2530-12-189-0539	GEHAEUSE	LEO 2
43	2530-12-189-5173	DECKEL	LEO 2
44	2530-12-190-8339	CAP, PROTECTIVE	LEO 2
45	2530-12-193-0045	WHEEL HUB	LEO 2
46	2530-12-193-8879	ARM ASSEMBLY,PIVOT,TRACK SUSPENSION	LEO 2
47	2530-12-197-6495	TENSION DEVICE,TRACK,VEHICULAR	LEO 2
48	2530-12-197-6496	TRACK, TENSIONNER RIGHT	LEO 2
49	2530-12-300-5548	ACCUMULATOR,HYDRAULIC	LEO 2
50	2530-12-300-5549	ACCUMULATOR,HYDRAULIC	LEO 2
51	2530-12-301-9988	BREMSE, SEGMENTROTO	LEO 2
52	2530-12-303-8009	BRAKE,SEGMENTED ROTOR	LEO 2
53	2530-12-304-1269	DECKEL, SEGMENTROTO	LEO 2
54	2530-12-304-4156	ABDECKUNG, BREMSE	LEO 2
55	2530-12-304-4158	DRUCKPLATTE, SCHEIB	LEO 2
56	2530-12-304-4160	PRESSURE PLATE, DIS	LEO 2
57	2530-12-310-3357	CONNECTOR, END	LEO 2
58	2530-12-311-1935	CONNECTOR, CENTER,	LEO 2
59	2530-12-312-5487	TRACK SHOE,VEHICULAR	LEO 2
60	2530-12-333-9663	SUSPENSION	LEO 2
61	2530-12-352-0018	GEHAEUSE, FESTSTELL	LEO 2
62	2530-12-352-0019	DRUCKPLATTE, SCHEIB	LEO 2
63	2540-12-176-3294	BLOWER, VEHICULAR	LEO 2
64	2540-12-184-5250	HOOK-KANCA	LEO 2
65	2590-12-187-4117	CABLE ASSEMBLY, SPEC	LEO 2
66	2590-12-190-3101	CABLE ASSEMBLY,SPECIAL PURPOSE,ELECTRICAL,BRANCHED	LEO 2
67	2815-12-186-3852	PISTON,INTERNAL COM	LEO 2
68	2815-12-186-3858	OIL PUMP ASSEMBLY,E	LEO 2
69	2815-12-193-9377	RING SET,PISTON	LEO 2
70	2815-12-305-2447	RING SET,PISTON	LEO 2
71	2815-12-392-4809	RING SET,PISTON	LEO 2
72	2815-12-414-4647	PISTON AND RING ASSEMBLY	LEO 2
73	2815-27-054-8018	PISTON,INTERNAL COMBUSTION ENGINE	LEO 2
74	2910-12-178-2386	FILTER,FLUID	LEO 2
75	2910-12-178-4847	FINAL CONTROLLING	LEO 2
76	2910-12-178-7054	FILTER ELEMENT	LEO 2
77	2910-12-178-8677	PUMP,FUEL,ELECTRICAL	LEO 2
78	2910-12-179-1745	KRAFTSTOFF. WEITERLESEN RIGHT	LEO 2
79	2910-12-179-1818	FILTER,FLUID	LEO 2
80	2910-12-192-1212	KRAFTSTOFF. WEITERLESEN LEFT	LEO 2

81	2910-12-192-1214	TANK, KRAFTSTOFF, V	LEO 2
82	2910-12-192-1217	MAZOT DEPOSU SOL	LEO 2
83	2910-12-195-1310	PUMP,FUEL,ELECTRICAL	LEO 2
84	2910-12-198-5265	PUMP,FUEL,ELECTRICAL	LEO 2
85	2910-12-304-2116	REGULATOR, FUEL FLOW	LEO 2
86	2910-12-350-2365	SUPPORT FUEL TANK	LEO 2
87	2910-12-350-2366	SUPPORT FUEL TANK	LEO 2
88	2910-12-350-2367	SUPPORT FUEL TANK	LEO 2
89	2910-12-350-2368	SUPPORT FUEL TANK	LEO 2
90	2910-12-355-4799	FILTER,FLUID	LEO 2
91	2920-12-142-8542	ANLASSER	LEO 2
92	2920-12-142-8551	GENERATOR,ENGINE ACCESSORY	LEO 2
93	2920-12-150-8563	STARTER,ENGINE,ELECTRICAL	LEO 2
94	2920-12-178-5320	GENERATOR,ENGINE ACCESSORY	LEO 2
95	2920-12-178-5739	STARTER,ENGINE,ELECTRICAL	LEO 2
96	2920-12-188-3130	STATOR,ENGINE GENER	LEO 2
97	2920-12-188-5781	ROTOR,GENERATOR	LEO 2
98	2920-12-330-6170	GENERATOR,ENGINE ACCESSORY	LEO 2
99	2920-12-373-7133	STARTER,ENGINE,ELECTRICAL	LEO 2
100	2930-12-177-2941	HYDRAULIKEINHEIT	LEO 2
101	2930-12-178-5310	RADIATOR,ENGINE COO	LEO 2
102	2930-12-184-7901	PUMPE WAVSER	LEO 2
103	2930-12-186-3884	RADIATOR	LEO 2
104	2940-12-178-4811	FILTEREINSATZ, DURC	LEO 2
105	2940-12-178-4812	BOOSTER	LEO 2
106	2940-12-178-5739	STARTER,ENGINE,ELECTRICAL	LEO 2
107	2940-12-190-6704	FILTER	LEO 2
108	2940-12-302-4020	BLOWER, AIR CLEANER	LEO 2
109	2940-12-333-6903	BLOWER, AIR CLEANER	LEO 2
110	2940-12-337-8993	FILTER ELEMENT,INTA	LEO 2
111	2940-12-337-9402	FILTEREINSATZ	LEO 2
112	3020-12-182-4284	SPROCKET WHEEL	LEO 2
113	3020-12-186-5943	GEAR,HELICAL	LEO 2
114	3020-12-186-6634	GEAR,HELICAL	LEO 2
115	3020-12-194-0933	ZAHNRAD, STIRN-, GE	LEO 2
116	3040-12-194-0934	WELLE, ABGESTUFT	LEO 2
117	3120-12-186-4547	BEARING HALF SET,SL	LEO 2
118	3120-12-186-4548	BEARING HALF SET,SL	LEO 2
119	3120-12-186-4549	BEARING HALF SET,SL	LEO 2
120	3120-12-186-4550	BEARING HALF SET,SL	LEO 2
121	3120-12-186-4551	BEARING HALF SET,SL	LEO 2
122	3120-12-186-4552	BEARING HALF SET,SL	LEO 2
123	3120-12-186-4553	BEARING HALF SET,SL	LEO 2
124	3120-12-186-4554	BEARING HALF SET,SL	LEO 2

125	3120-12-186-4555	BEARING HALF SET,SL	LEO 2
126	3120-12-186-4556	BEARING HALF SET,SL	LEO 2
127	3120-12-186-4557	BEARING HALF SET,SL	LEO 2
128	3120-12-186-4558	BEARING HALF SET,SL	LEO 2
129	3120-12-186-4559	BEARING HALF SET,SL	LEO 2
130	3120-12-186-4560	BEARING HALF SET,SL	LEO 2
131	3120-12-186-4561	BEARING HALF SET,SL	LEO 2
132	3120-12-186-4562	BEARING HALF SET,SL	LEO 2
133	3120-12-186-4563	BEARING HALF SET,SL	LEO 2
134	3120-12-186-4564	BEARING HALF SET,SL	LEO 2
135	3120-12-186-4565	BEARING HALF SET,SL	LEO 2
136	3120-12-186-4566	BEARING HALF SET,SL	LEO 2
137	3120-12-186-4568	BEARING,SLEEVE	LEO 2
138	3120-12-186-4569	BEARING,SLEEVE	LEO 2
139	3120-12-186-4570	BEARING,SLEEVE	LEO 2
140	3120-12-186-4571	BEARING,SLEEVE	LEO 2
141	3120-12-188-4078	BEARING,SLEEVE	LEO 2
142	3120-12-198-7531	BEARING,SLEEVE	LEO 2
143	3120-12-198-7532	BEARING,SLEEVE	LEO 2
144	3120-12-311-2560	BEARING HALF SET,SL	LEO 2
145	3120-12-311-2561	BEARING HALF SET,SL	LEO 2
146	3120-12-311-2562	BEARING HALF SET,SL	LEO 2
147	3120-12-311-2563	BEARING HALF SET,SL	LEO 2
148	3120-12-311-2564	BEARING HALF SET,SL	LEO 2
149	3120-12-311-2565	BEARING HALF SET,SL	LEO 2
150	3120-12-311-2566	BEARING HALF SET,SL	LEO 2
151	3120-12-311-2567	BEARING HALF SET,SL	LEO 2
152	3120-12-311-2568	BEARING HALF SET,SL	LEO 2
153	3120-12-311-2569	BEARING HALF SET,SL	LEO 2
154	4210-12-173-8432	CONTROL- AND TRIGGER	LEO 2
155	4240-12-147-4790	FILTER	LEO 2
156	4240-12-147-4791	FILTER-GAS	LEO 2
157	4240-12-177-0758	FILTER,PARTICULATE	LEO 2
158	4320-12-164-9401	PUMP,RADIAL PISTONS	LEO 2
159	4320-12-176-4733	PUMP UNIT,CENTRIFUGAL	LEO 2
160	4320-12-177-1619	MOTOR-PUMP,HYDRAULIC	LEO 2
161	4320-12-177-4357	PUMP UNIT,CENTRIFUGAL	LEO 2
162	4320-12-178-7742	PUMP,ROTARY	LEO 2
163	4320-12-178-7743	PUMP,ROTARY	LEO 2
164	4320-12-185-1776	PUMP UNIT,RECIPROCA	LEO 2
165	4320-12-311-3797	PUMP UNIT,RECIPROCA	LEO 2
166	4810-12-170-7040	VENTILTEILBAUGRUPPE	LEO 2
167	4810-12-170-7041	VALVE ASSEMBLY, GLO	LEO 2
168	4820-12-164-9397	VALVE,SAFETY RELIEF	LEO 2

169	4820-12-164-9398	VALVE,SAFETY RELIEF	LEO 2
170	4820-12-164-9399	VENTIL	LEO 2
171	4910-12-187-8981	STAND,MAINTENANCE,AUTOMOTIVE ENGINE	LEO 2
172	5077 104 005	PARKING BRAKE VALVE	LEO 2
173	5077 121 202	HYD POWER PACKAGE UNIT	LEO 2
174	5077 121 203	HYD POWER PACKAGE UNIT	LEO 2
175	5077 202 006	VENTIL BLOCK (PLATE)	LEO 2
176	5077 204 080	HAUPTCYLINDER	LEO 2
177	5305-12-190-9676	SCREW,SELF-LOCKING	LEO 2
178	5305-12-193-4540	SCREW,MACHINE	LEO 2
179	5306-12-318-2064	BOLT	LEO 2
180	5330-12-183-0907	CONTA	LEO 2
181	5340-12-166-0867	SEAT ,BALL SOCKET	LEO 2
182	5340-12-166-3892	SEAT ,BALL SOCKET	LEO 2
183	5365-12-193-6470	SPACER,SLEEVE	LEO 2
184	5365-12-300-5019	ABSTANDSHUELSE	LEO 2
185	5855-12-196-3256	BETRACHTUNGSGERAET	LEO 2
186	5935-12-186-4316	CONNECTOR, RECEPTACL	LEO 2
187	5935-12-189-0041	CONNECTOR BODY, PLUG	LEO 2
188	6105-12-148-2962	MOTOR,DIRECT CURRENT	LEO 2
189	6105-12-151-5070	ARMATURE,MOTOR	LEO 2
190	6105-12-154-1097	MOTOR,DIRECT CURRENT	LEO 2
191	6105-12-158-1674	MOTOR,DIRECT CURRENT	LEO 2
192	6105-12-175-3485	STATOR,MOTOR	LEO 2
193	6105-12-186-7426	MOTOR,DIRECT CURRENT	LEO 2
194	6105-12-186-7428	ARMATURE	LEO 2
195	6105-12-186-8105	PACKING ,PREFORMED	LEO 2
196	6105-12-190-0931	MOTOR DIRECT CURREN	LEO 2
197	6105-12-191-1084	ELECTRIC MOTOR	LEO 2
198	6105-12-191-7389	MOTOR,DIRECT CURREN	LEO 2
199	6105-12-300-2249	MOTOR,DIRECT CURRENT	LEO 2
200	6105-12-303-5583	MOTOR,DIRECT CURRENT	LEO 2
201	6105-12-303-9886	MOTOR,DIRECT CURRENT	LEO 2
202	6105-12-306-4496	MOTOR,DIRECT CURRENT	LEO 2
203	6110-12-183-2269	DISTRIBUTION BOX	LEO 2
204	6110-12-187-5892	DISTRIBUTION BOX	LEO 2
205	6110-12-190-0138	ELECTRONIC UNIT	LEO 2
206	6220-12-151-4411	STOP LIGHT	LEO 2
207	6680-12-199-5083	THERMOSTAT,FLOW CON	LEO 2
208	2930-12-352-8149 NO: 8372002901	PARÇA WATER PUMP	LEO 2