



Alexander Defense Corp. M1 ABRAMS Parts List

#	NSN	Name	End Use Item
1	1015-01-180-3510	CRANK ASSEMBLY	M1 Abrams
2	1015-01-180-3512	BRAKE ASSEMBLY	M1 Abrams
3	1240-01-390-4980	PERISCOPE,ARMORED VEHICLE	M1 Abrams
4	2510-01-063-5838	TORSION BAR	M1 Abrams
5	2510-01-075-4915	FENDER,VEHICULAR	M1 Abrams
6	2510-01-078-4321	GRILLE,METAL	M1 Abrams
7	2510-01-197-5550	FENDER,VEHICULAR	M1 Abrams
8	2510-01-197-5551	FENDER,VEHICULAR	M1 Abrams
9	2510-01-317-5492	GRILLE,METAL	M1 Abrams
10	2510-01-317-5493	GRILLE,METAL	M1 Abrams
11	2510-01-345-8881	TORSION BAR,SUSPENS	M1 Abrams
12	2510-01-345-8882	TORSION BAR,SUSPENS	M1 Abrams
13	2510-01-350-7070	SHOCK ABSORBER,DIRECT ACTION	M1 Abrams
14	2510-01-456-3625	DOOR,HATCH,VEHICLE	M1 Abrams
15	2510-01-459-1662	PANEL,VEHICULAR OPE	M1 Abrams
16	2510-01-478-6339	PARTS KIT,DOOR,VEHI	M1 Abrams
17	2510-01-542-4310	HATCH,ROOF ASSEMBLY	M1 Abrams
18	2520-01-133-5302	DUCT,OIL COOLER,FAN	M1 Abrams
19	2520-01-235-0450	MODIFICATION KIT,VE	M1 Abrams
20	2520-01-288-8012	YOKE,UNIVERSAL JOIN	M1 Abrams
21	2530-01-063-5666	HUB,WHEEL,VEHICULAR	M1 Abrams
22	2530-01-069-5932	HOSE AND TUBE ASSEM	M1 Abrams
23	2530-01-118-2872	PARTS KIT,HYDRAULIC	M1 Abrams
24	2530-01-119-4098	COVER,BRAKE,STEERIN	M1 Abrams
25	2530-01-179-1416	IDLER ARM	M1 Abrams
26	2530-01-179-1417	ARM ASSEMBLY,PIVOT,	M1 Abrams
27	2530-01-295-3112	PARTS KIT,TRACK PAD	M1 Abrams
28	2530-01-295-3115	WEDGE,SELF-LOCKING	M1 Abrams
29	2530-01-329-4839	CABLE AND CONDUIT A	M1 Abrams
30	2530-01-345-8887	M1 TRACK TENSION DEVICE	M1 Abrams
31	2530-01-347-7637	HOUSING,SHOCK ABSOR	M1 Abrams
32	2530-01-373-5711	HUB ASSEMBLY,VEHICU	M1 Abrams
33	2530-01-435-5175	TRACK SHOE ASSEMBLY	M1 Abrams
34	2530-01-501-0837	PARTS KIT,HYDRAULIC	M1 Abrams
35	2530-01-531-9543	ARM ASSY	M1 Abrams
36	2530-01-533-9159	ARM ASSEMBLY,PIVOT,TRACK SUSPENSION	M1 Abrams
37	2530-01-588-7023	ARM ASSEMBLY,PIVOT,	M1 Abrams

38	2530-01-588-7026	ARM ASSEMBLY,PIVOT,	M1 Abrams
39	2540-01-071-9046	ARMOR,SUPPLEMENTAL,	M1 Abrams
40	2540-01-071-9047	ARMOR,SUPPLEMENTAL,	M1 Abrams
41	2540-01-071-9064	PINTLE ASSEMBLY,TOW	M1 Abrams
42	2540-01-126-3567	BOX,ACCESSORIES STOWAGE	M1 Abrams
43	2540-01-133-5424	CUSHION,SEAT BACK,V	M1 Abrams
44	2540-01-144-1459	CUSHION,SEAT BACK,V	M1 Abrams
45	2540-01-186-2393	CUSHION,SEAT,VEHICU	M1 Abrams
46	2540-01-288-0728	SUPPORT,SEAT,VEHICU	M1 Abrams
47	2540-01-319-9002	CURTAIN,VEHICULAR	M1 Abrams
48	2540-01-456-0508	GUARD SPLASH	M1 Abrams
49	2590-01-072-4182	SCREEN,PLATFORM-RAC	M1 Abrams
50	2590-01-075-2827	CONTROL ASSEMBLY,PU	M1 Abrams
51	2590-01-276-7040	MOLDBOARD,EXTENSION	M1 Abrams
52	2590-01-276-7041	MOLDBOARD,EXTENSION	M1 Abrams
53	2590-01-276-7043	MOLDBOARD,LEFTSIDE	M1 Abrams
54	2590-01-276-7046	MOLDBOARD,EXTENSION	M1 Abrams
55	2590-01-276-7047	MOLDBOARD,EXTENSION	M1 Abrams
56	2590-01-277-0059	CONTROL BOX ASSEMBL	M1 Abrams
57	2590-01-278-5726	BELT ASSEMBLY,EMERG	M1 Abrams
58	2590-01-320-1292	CABLE ASSEMBLY,CONT	M1 Abrams
59	2590-01-357-1552	MANIFOLD ASSEMBLY	M1 Abrams
60	2590-01-366-7259	BLASTING MACHINE AS	M1 Abrams
61	2590-01-385-2636	MODIFICATION KIT,VE	M1 Abrams
62	2590-01-466-4774	RACK,AMMUNITION STO	M1 Abrams
63	2590-01-473-3999	KIT,CENTERLINE DEF	M1 Abrams
64	2590-01-533-1742	CABLE ASSEMBLY,CONT	M1 Abrams
65	2590-01-593-4922	CONTROL ASSEMBLY,PU	M1 Abrams
66	3010-01-069-0484	DRIVE UNIT, ANGLE	M1 Abrams
67	3010-01-178-7479	DRIVE BOX	M1 Abrams
68	3010-01-497-0514	PARTS KIT,GEARBOX	M1 Abrams
69	3020-01-180-3519	GEAR,SPUR	M1 Abrams
70	3020-01-518-3215	SPROCKET WHEEL	M1 Abrams
71	3040-01-158-3258	SHAFT,SHOULDERED	M1 Abrams