



## Alexander Defense Corp. M-60 Parts List

| #  | NSN              | Name                                 | End Use Item |
|----|------------------|--------------------------------------|--------------|
| 1  | 10885766         | WIRING HARNESS,                      | M-60         |
| 2  | 10911122         | TANK,FUEL,ENGINE                     | M-60         |
| 3  | 10933845         | BILGE PUMP ASSEMBLY                  | M-60         |
| 4  | 11673739         | TANK,FUEL,ENGINE                     | M-60         |
| 5  | 12251859         | WHEEL AND HUB                        | M-60         |
| 6  | 12251861         | ROLLER ASSEMBLY                      | M-60         |
| 7  | 12251872         | ROLLER ASSEMBLY                      | M-60         |
| 8  | -                | Shoe Body                            | M-60         |
| 9  | -                | Pin                                  | M-60         |
| 10 | -                | Pad Assembly                         | M-60         |
| 11 | -                | End Connector                        | M-60         |
| 12 | 2510-00-556-5137 | BRACKET, TRAVEL LOCK                 | M-60         |
| 13 | 1005-01-061-0799 | DEFLECTOR, LINK-CARTRIDGE CASE       | M-60         |
| 14 | 1005-01-084-9847 | MOUNT, MACHINE GUN                   | M-60         |
| 15 | 1015-00-067-7909 | BRACKET, SEAT MOUNT                  | M-60         |
| 16 | 1015-00-088-2006 | SUPPORT, ELEVATING AND FIRING CRADLE | M-60         |
| 17 | 1015-00-329-1712 | COLLAR, BREECH RING, ADAPTER         | M-60         |
| 18 | 1015-00-332-0066 | GEAR SHAFT ASSY                      | M-60         |
| 19 | 1015-00-332-0067 | GEAR ASSY                            | M-60         |
| 20 | 1015-00-446-6231 | CIRCUIT TESTER, FIRING               | M-60         |
| 21 | 1015-00-678-4275 | EXTRACTOR, CARTRIDGE                 | M-60         |
| 22 | 1015-00-678-4300 | STOP, BREECHBLOCK                    | M-60         |
| 23 | 1015-00-699-9080 | BLOWER ASSY, VENTILATOR, GUN         | M-60         |
| 24 | 1015-00-725-5266 | MOUNT, AMMUNITION RACK               | M-60         |
| 25 | 1015-00-837-8842 | BLOCK, EJECTOR, CARTRIDGE            | M-60         |
| 26 | 1015-01-087-3635 | LOCATOR                              | M-60         |

|           |                  |                                         |      |
|-----------|------------------|-----------------------------------------|------|
| <b>27</b> | 1015-01-208-2254 | TURRET PLATFORM                         | M-60 |
| <b>28</b> | 1015-01-210-3689 | STRUT,TURRET DRIVE                      | M-60 |
| <b>29</b> | 1015-01-223-5435 | BOSS,SHIELD                             | M-60 |
| <b>30</b> | 11599S73         | GUIDE PART                              | M-60 |
| <b>31</b> | 1220-01-016-2266 | DRIVE,BALLISTICS                        | M-60 |
| <b>32</b> | 1220-01-018-9171 | SENSOR,CANT ANGLE                       | M-60 |
| <b>33</b> | 1220-01-019-0006 | MOTOR ASSEMBLY,MIRROR DRIVE             | M-60 |
| <b>34</b> | 1220-01-019-4545 | TACHOMETER ASSEMBLY                     | M-60 |
| <b>35</b> | 1220-01-071-2572 | KNOB ASSEMBLY                           | M-60 |
| <b>36</b> | 1240-00-344-4643 | PERISCOPE M27                           | M-60 |
| <b>37</b> | 1240-01-063-1381 | CELL ASSEMBLY,OPTICAL INSTRUMENT        | M-60 |
| <b>38</b> | 1240-01-063-6135 | POWER CONVERTER UNIT                    | M-60 |
| <b>39</b> | 1240-01-082-3686 | CELL ASSEMBLY,OPTICAL INSTRUMENT        | M-60 |
| <b>40</b> | 1240-01-499-7958 | KIT,BORESIGHT,MACHI                     | M-60 |
| <b>41</b> | 1240-01-543-0996 | RETICLE ASSEMBLY,OPTICAL INSTRUMENT     | M-60 |
| <b>42</b> | 1265-01-021-7287 | CONTROL,GUNNERS,LASER RANGING           | M-60 |
| <b>43</b> | 1290-00-370-3467 | INDICATOR,AZIMUTH                       | M-60 |
| <b>44</b> | 1290-01-206-0055 | MODIFICATION KIT,FIRE CONTROL EQUIPMENT | M-60 |
| <b>45</b> | 1375-01-227-7818 | PARTS KIT,TILE,ARMOR                    | M-60 |
| <b>46</b> | 1375-01-227-7819 | PARTS KIT,TILE,ARMOR                    | M-60 |
| <b>47</b> | 1420-00-250-8622 | COIL AND COVER ASSE                     | M-60 |
| <b>48</b> | 1560-01-132-2480 | SKIN                                    | M-60 |
| <b>49</b> | 1680-01-491-3977 | PAD ASSEMBLY PART                       | M-60 |
| <b>50</b> | 10S46915         | PUMP, FUEL,                             | M-60 |
| <b>51</b> | 2342-00-105-6142 | DOOR                                    | M-60 |
| <b>52</b> | 2510-00-014-2483 | DOOR ASSEMBLY GRILL,                    | M-60 |
| <b>53</b> | 2510-00-040-0858 | TORSION BAR, SUSPENS, RIGHT,            | M-60 |

|           |                  |                                     |      |
|-----------|------------------|-------------------------------------|------|
| <b>54</b> | 2510-00-040-0859 | TORSION BAR, SUSPENS, LEFT, COUNTER | M-60 |
| <b>55</b> | 2510-00-105-6154 | DOOR,HATCH,VEHICLE                  | M-60 |
| <b>56</b> | 2510-00-105-6155 | DOOR,HATCH,VEHICLE                  | M-60 |
| <b>57</b> | 2510-00-108-6203 | GUIDE ASSEMBLY,                     | M-60 |
| <b>58</b> | 2510-00-115-4327 | DOOR,HATCH,VEHICLE                  | M-60 |
| <b>59</b> | 2510-00-179-5526 | SHOCK ABSORBER,DIRE                 | M-60 |
| <b>60</b> | 2510-00-226-2131 | DOOR,HATCH,VEHICLE                  | M-60 |
| <b>61</b> | 2510-00-226-2656 | DOOR,HATCH,VEHICLE                  | M-60 |
| <b>62</b> | 2510-00-269-4842 | DOOR ASSEMBLY REAR                  | M-60 |
| <b>63</b> | 2510-00-487-9475 | DOOR,HATCH,VEHICLE                  | M-60 |
| <b>64</b> | 2510-00-556-5137 | BRACKET,TRAVEL LOCK                 | M-60 |
| <b>65</b> | 2510-00-559-1814 | BRACKET,TRAVEL LOCK                 | M-60 |
| <b>66</b> | 2510-00-752-8974 | TORSION BAR,SUSPENS                 | M-60 |
| <b>67</b> | 2510-00-752-8976 | TORSION BAR,SUSPENS                 | M-60 |
| <b>68</b> | 2510-00-752-8981 | TORSION BAR,SUSPENS                 | M-60 |
| <b>69</b> | 2510-00-752-8983 | TORSION BAR,SUSPENS                 | M-60 |
| <b>70</b> | 2510-00-837-8909 | MOUNT, ENGINE,                      | M-60 |
| <b>71</b> | 2510-00-851-4972 | HATCH DRIVERS ESC                   | M-60 |
| <b>72</b> | 2510-00-866-5844 | COVER                               | M-60 |
| <b>73</b> | 2510-00-930-2012 | FENDER, VEHICULAR                   | M-60 |
| <b>74</b> | 2510-00-986-5167 | DOOR ASSEMBLY,TOP D                 | M-60 |
| <b>75</b> | 2510-01-021-5745 | COVER ASSEMBLY,                     | M-60 |
| <b>76</b> | 2510-01-022-6175 | DOOR, ACCESS                        | M-60 |
| <b>77</b> | 2510-01-074-8285 | SUPPORT,FENDER                      | M-60 |
| <b>78</b> | 2510-01-079-2961 | SPRING ASSEMBLY,LEAF                | M-60 |
| <b>79</b> | 2510-01-535-5905 | LEVER,ACCELERATOR                   | M-60 |

|            |                  |                                             |      |
|------------|------------------|---------------------------------------------|------|
| <b>80</b>  | 2520-00-049-5465 | DIFFERENTIAL GEAR U                         | M-60 |
| <b>81</b>  | 2520-00-177-8126 | SPIDER, UNIVERSAL                           | M-60 |
| <b>82</b>  | 2520-00-332-0069 | CARRIER,DIFFERENTIA                         | M-60 |
| <b>83</b>  | 2520-00-678-4281 | DISK,CLUTCH,VEHICULAR                       | M-60 |
| <b>84</b>  | 2520-00-722-3810 | WINCH ASSY                                  | M-60 |
| <b>85</b>  | 2520-00-732-4016 | ADAPTER ASSEMBLY,PUMP,TRANSMISSION          | M-60 |
| <b>86</b>  | 2520-00-737-9233 | FLANGE QUICK DISCON                         | M-60 |
| <b>87</b>  | 2520-00-936-5341 | PIVOT ASSEMBLY                              | M-60 |
| <b>88</b>  | 2520-01-023-3719 | CARRIER,FINAL DRIVE                         | M-60 |
| <b>89</b>  | 2520-01-039-9579 | CASE AND CARRIER AS                         | M-60 |
| <b>90</b>  | 2520-01-058-1161 | FINAL DRIVE ASSEMBL                         | M-60 |
| <b>91</b>  | 2520-01-076-4133 | CONVERSION KIT,TRAN                         | M-60 |
| <b>92</b>  | 2520-01-134-1843 | ADAPTER ASSEMBLY,                           | M-60 |
| <b>93</b>  | 2530-00-004-2301 | ARM ASSEMBLY,PIVOT,                         | M-60 |
| <b>94</b>  | 2530-00-039-9153 | Wedge Nut                                   | M-60 |
| <b>95</b>  | 2530-00-150-5893 | GUIDE PART OF KIT                           | M-60 |
| <b>96</b>  | 2530-00-150-5894 | PARTS KIT,TRACK WED                         | M-60 |
| <b>97</b>  | 2530-00-150-5895 | Pad Kit                                     | M-60 |
| <b>98</b>  | 2530-00-150-5896 | Connector Kit                               | M-60 |
| <b>99</b>  | 2530-00-150-5897 | TRACK SHOE, VEHICULA                        | M-60 |
| <b>100</b> | 2530-00-248-0944 | CYLINDER ASSEMBLY,                          | M-60 |
| <b>101</b> | 2530-00-293-5137 | WHEEL,SOLID RUBBER                          | M-60 |
| <b>102</b> | 2530-00-337-6969 | M60 (T142) Series<br>(Complete Track Chain) | M-60 |
| <b>103</b> | 2530-00-597-9995 | SPINDLE, WHEEL, NONDR                       | M-60 |
| <b>104</b> | 2530-00-597-9997 | SPINDLEWHEEL, NONDR                         | M-60 |
| <b>105</b> | 2530-00-602-5738 | LINK ASSEMBLY, ADJUS , RIGHT                | M-60 |

|            |                  |                                    |      |
|------------|------------------|------------------------------------|------|
| <b>106</b> | 2530-00-602-5739 | LINK ASSEMBLY, ADJUS , LEFT        | M-60 |
| <b>107</b> | 2530-00-678-3147 | ARM ASSY, ROAD WHEEL               | M-60 |
| <b>108</b> | 2530-00-678-3158 | ARM,STEERING GEAR                  | M-60 |
| <b>109</b> | 2530-00-678-4131 | HUB,WHEEL,VEHICULAR                | M-60 |
| <b>110</b> | 2530-00-701-3976 | WHEEL,SOLID RUBBER                 | M-60 |
| <b>111</b> | 2530-00-701-4011 | ANCHOR                             | M-60 |
| <b>112</b> | 2530-00-704-4259 | Center Guide                       | M-60 |
| <b>113</b> | 2530-00-706-8219 | HOOK,TOW                           | M-60 |
| <b>114</b> | 2530-00-706-9545 | CAP PART                           | M-60 |
| <b>115</b> | 2530-00-736-4134 | HUB                                | M-60 |
| <b>116</b> | 2530-00-736-4260 | HUB, WHEEL, VEHICULAR              | M-60 |
| <b>117</b> | 2530-00-736-4672 | SEAL ASY HUB                       | M-60 |
| <b>118</b> | 2530-00-800-1241 | ARM ASSEMBLY, ROAD W , NO 2, LEFT  | M-60 |
| <b>119</b> | 2530-00-800-1244 | ARM ASSEMBLY, PIVOT, NO 2, RIGHT   | M-60 |
| <b>120</b> | 2530-00-871-2855 | ARM ASSEMBLY,PIVOT,                | M-60 |
| <b>121</b> | 2530-00-871-2856 | ARM ASSEMBLY, PIVOT, LEFT          | M-60 |
| <b>122</b> | 2530-00-871-2859 | ARM ASSEMBLY, PIVOT, NO 6, RIGHT   | M-60 |
| <b>123</b> | 2530-00-871-2860 | ARM ASSEMBLY, ROAD W , NO 6 LEFT   | M-60 |
| <b>124</b> | 2530-00-908-6342 | ARM ASSEMBLY, PIVOT, LEFT          | M-60 |
| <b>125</b> | 2530-00-908-6343 | ARM ASSEMBLY, PVOT, RIGHT          | M-60 |
| <b>126</b> | 2530-00-978-2068 | CYLINDER ASSEMBLY                  | M-60 |
| <b>127</b> | 2530-01-042-4047 | ARM ASSEMBLY, PIVOT                | M-60 |
| <b>128</b> | 2530-01-077-1682 | HOUSING, TORSION BAR , NO 1, LEFT  | M-60 |
| <b>129</b> | 2530-01-077-1683 | HOUSING, TORSION BAR , NO 1, RIGHT | M-60 |
| <b>130</b> | 2530-01-096-9298 | TRACK ASSEMBLY, TANK               | M-60 |
| <b>131</b> | 2530-01-160-8109 | TRACK SHOE, VEHICULA               | M-60 |

|            |                  |                                              |      |
|------------|------------------|----------------------------------------------|------|
| <b>132</b> | 2530-01-278-3737 | Assembly of 80 Shoes<br>(1 Side Track Chain) | M-60 |
| <b>133</b> | 2530-01-537-2035 | HUB AND ARM , NO 6, RIGHT ROADWHEEL          | M-60 |
| <b>134</b> | 2530-01-537-2164 | HUB AND ARM , NO 6, LEFT ROADWHEEL           | M-60 |
| <b>135</b> | 2530-01-537-2165 | HUB AND ARM, LEFT                            | M-60 |
| <b>136</b> | 2530-01-537-2166 | HUB AND ARM, RIGHT                           | M-60 |
| <b>137</b> | 2530-01-537-2176 | ARM,CONTROL,VEHICUL                          | M-60 |
| <b>138</b> | 2530-01-537-2177 | ARM,CONTROL,VEHICUL                          | M-60 |
| <b>139</b> | 2530-01-537-2178 | HUB AND ARM, NO 2, LEFT ROADWHEEL            | M-60 |
| <b>140</b> | 2530-01-537-2180 | HUB AND ARM , NO2, RIGHT ROADWHEEL           | M-60 |
| <b>141</b> | 2530-01-602-5736 | LINK BRAKE SHOE                              | M-60 |
| <b>142</b> | 2530-01-602-5739 | LINK BRAKE SHOE LEVER                        | M-60 |
| <b>143</b> | 2530-01-701-4011 | ANCHOR                                       | M-60 |
| <b>144</b> | 2540-00-047-3926 | PINTLE ASSESBLY,                             | M-60 |
| <b>145</b> | 2540-00-067-7933 | COVER,BOX,ACCESSORIES STOWAGE                | M-60 |
| <b>146</b> | 2540-00-168-2681 | COVER, BOX STOWAGE                           | M-60 |
| <b>147</b> | 2540-00-168-2723 | SUPPORT SEAT                                 | M-60 |
| <b>148</b> | 2540-00-226-1942 | SLEEVE,PINTLE HOOK                           | M-60 |
| <b>149</b> | 2540-00-621-1360 | BOX, ACCESSORIES STO                         | M-60 |
| <b>150</b> | 2540-00-706-8219 | HOOK, TOW                                    | M-60 |
| <b>151</b> | 2540-00-740-4600 | PEDESTAL, SEAT                               | M-60 |
| <b>152</b> | 2540-00-851-4988 | BOX,ACCESSORIES STOWAGE                      | M-60 |
| <b>153</b> | 2540-00-937-4267 | LOCK,SEAT,BACK                               | M-60 |
| <b>154</b> | 2540-00-983-6882 | BOX,ACCESSORIES STOWAGE                      | M-60 |
| <b>155</b> | 2540-01-061-2332 | FORDING KIT,DEEP WATER                       | M-60 |
| <b>156</b> | 2540-01-083-0691 | HEATER, VEHICULAR,                           | M-60 |
| <b>157</b> | 2540-01-085-0760 | RELEASE,FIRE EXTING                          | M-60 |

|            |                  |                                                 |      |
|------------|------------------|-------------------------------------------------|------|
| <b>158</b> | 2540-01-166-6382 | HOUSING ASSEMBLY                                | M-60 |
| <b>159</b> | 2540-01-492-2409 | HOUSING,AIR INTAKE,                             | M-60 |
| <b>160</b> | 2541-01-065-9730 | BOX,AMMUNITION STOWAGE                          | M-60 |
| <b>161</b> | 2541-01-302-8673 | BLOCK,DIRECT VISION                             | M-60 |
| <b>162</b> | 2590-00-092-9131 | LEAD, ELECTRICAL,                               | M-60 |
| <b>163</b> | 2590-00-129-5349 | FILLER NECK,VEHICUL                             | M-60 |
| <b>164</b> | 2590-00-177-8259 | COVER, STOWAGE BOX , RIGHT                      | M-60 |
| <b>165</b> | 2590-00-484-3587 | BASE, PIVOT SHIFTING CONTROLS                   | M-60 |
| <b>166</b> | 2590-00-606-2377 | WIRING HARNESS,                                 | M-60 |
| <b>167</b> | 2590-00-606-2395 | CABLE ASSEMBLY,                                 | M-60 |
| <b>168</b> | 2590-00-709-1836 | BASE ASSEMBLY,                                  | M-60 |
| <b>169</b> | 2590-00-735-4063 | SWITCH, BEAM SELECTI                            | M-60 |
| <b>170</b> | 2590-00-752-5962 | VALVE ASSEMBLY, PCPP                            | M-60 |
| <b>171</b> | 2590-00-911-3596 | ENCLOSURE ASSEMBLY                              | M-60 |
| <b>172</b> | 2590-01-021-1299 | WIRING HARNESS,                                 | M-60 |
| <b>173</b> | 2590-01-021-9825 | GUARD                                           | M-60 |
| <b>174</b> | 2590-01-032-7409 | WIRING HARNESS                                  | M-60 |
| <b>175</b> | 2590-01-032-7410 | WIRING HARNESS,                                 | M-60 |
| <b>176</b> | 2590-01-076-2042 | RACK,AMMUNITION STOWAGE                         | M-60 |
| <b>177</b> | 2590-01-090-0970 | MODIFICATION KIT,VEHICULAR EQUIPMENT COMPONENTS | M-60 |
| <b>178</b> | 2590-01-145-9141 | MODIFICATION KIT,VEHICULAR EQUIPMENT COMPONENTS | M-60 |
| <b>179</b> | 2590-01-145-9142 | MODIFICATION KIT,VEHICULAR EQUIPMENT COMPONENTS | M-60 |
| <b>180</b> | 2590-01-145-9143 | MODIFICATION KIT,VEHICULAR EQUIPMENT COMPONENTS | M-60 |
| <b>181</b> | 2590-01-218-2106 | FIXTURE, LINK TEST,                             | M-60 |
| <b>182</b> | 2590-01-258-7814 | TANK,OIL,HYDRAULIC SYSTEM                       | M-60 |
| <b>183</b> | 2815-01-005-2993 | HOUSING ASSEMBLY                                | M-60 |

|            |                  |                                       |      |
|------------|------------------|---------------------------------------|------|
| <b>184</b> | 2815-01-154-1396 | MANIFOLD,SCAVENGE L                   | M-60 |
| <b>185</b> | 2815-01-507-0758 | BLOCK                                 | M-60 |
| <b>186</b> | 2840-01-135-8977 | CONE, EXHAUST                         | M-60 |
| <b>187</b> | 2910-00-025-3493 | FILTER,FLUID                          | M-60 |
| <b>188</b> | 2910-00-203-3322 | FILTER ELEMENT,FLUI                   | M-60 |
| <b>189</b> | 2910-00-600-9016 | TANK,FUEL,ENGINE                      | M-60 |
| <b>190</b> | 2910-00-923-4248 | PUMP, FUEL                            | M-60 |
| <b>191</b> | 2910-00-933-4628 | TANK,FUEL,ENGINE                      | M-60 |
| <b>192</b> | 2910-01-022-6967 | FILTER ELEMENT,FLUID                  | M-60 |
| <b>193</b> | 2910-01-050-2520 | PARTS KIT,FUEL INJECTOR,DIESEL ENGINE | M-60 |
| <b>194</b> | 2910-01-383-5647 | PUMP ASSEMBLY                         | M-60 |
| <b>195</b> | 2920-00-785-0833 | STARTER ENGINE ELEC                   | M-60 |
| <b>196</b> | 2920-01-139-3722 | STARTER,ENGINE,ELEC                   | M-60 |
| <b>197</b> | 2920-01-142-8260 | FILTER ELEMENT                        | M-60 |
| <b>198</b> | 2930-00-774-9446 | CLUTCH,FAN,ENGINE                     | M-60 |
| <b>199</b> | 2940-01-035-9826 | AIR CLEANER,INTAKE, RIGHT             | M-60 |
| <b>200</b> | 2940-01-035-9827 | AIR CLEANER,INTAKE, LEFT              | M-60 |
| <b>201</b> | 2940-01-121-1221 | FILTER, GROUND                        | M-60 |
| <b>202</b> | 2940-01-137-3895 | MODIFICATION KIT,ENGINE ACCESSORIES   | M-60 |
| <b>203</b> | 2940-01-142-8260 | FILTER ASSEMBLY,AIR                   | M-60 |
| <b>204</b> | 2940-01-152-2386 | AIR CLEANER,TURBINE ENGINE            | M-60 |
| <b>205</b> | 2940-01-152-2387 | AIR CLEANER,TURBINE ,1RIGHT           | M-60 |
| <b>206</b> | 2990-01-029-7980 | PIPE,EXHAUST                          | M-60 |
| <b>207</b> | 2990-01-161-5340 | FLANGE,ASSEMBLY                       | M-60 |
| <b>208</b> | 3010-00-446-7521 | GEAR SUBASSEMBLY,SP                   | M-60 |
| <b>209</b> | 3010-00-972-2624 | DRIVE UNIT,HYDRAULIC                  | M-60 |

|            |                  |                               |      |
|------------|------------------|-------------------------------|------|
| <b>210</b> | 3020-00-252-5637 | SPROCKET WHEEL LEFT AND RIGHT | M-60 |
| <b>211</b> | 3020-00-692-5026 | GEAR SET, FINAL DRIV          | M-60 |
| <b>212</b> | 3020-00-722-3633 | SPROCKET WHEEL                | M-60 |
| <b>213</b> | 3020-01-456-0570 | GEAR,SPUR                     | M-60 |
| <b>214</b> | 3040-00-045-6031 | CONNECTING LINK,RIGID         | M-60 |
| <b>215</b> | 3040-00-111-6655 | CONNECTING LINK, RIG          | M-60 |
| <b>216</b> | 3040-00-119-0838 | LEVER, REMOTE CONTROL         | M-60 |
| <b>217</b> | 3040-00-133-9570 | LEVER,REMOTE CONTROL          | M-60 |
| <b>218</b> | 3040-00-134-7793 | LEVER,REMOTE CONTROL          | M-60 |
| <b>219</b> | 3040-00-178-1066 | LEVER,REMOTE CONTROL          | M-60 |
| <b>220</b> | 3040-00-230-0284 | LEVER, REMOTE CONTROL         | M-60 |
| <b>221</b> | 3040-00-238-9141 | LEVER,REMOTE CONTROL          | M-60 |
| <b>222</b> | 3040-00-332-0064 | GEARSHAFT,MULTIPLE            | M-60 |
| <b>223</b> | 3040-00-332-0065 | GEARSHAFT,MULTIPLE            | M-60 |
| <b>224</b> | 3040-00-394-3016 | CRANKSHAFT DAMPER             | M-60 |
| <b>225</b> | 3040-00-446-7520 | GEARSHAFT,MULTIPLE            | M-60 |
| <b>226</b> | 3040-00-566-3827 | SHAFT,STRAIGHT                | M-60 |
| <b>227</b> | 3040-00-566-3834 | CONNECTING LINK,RIGID         | M-60 |
| <b>228</b> | 3040-00-566-3835 | CONNECTING LINK,RIGID         | M-60 |
| <b>229</b> | 3040-00-566-3840 | SHAFT,STRAIGHT                | M-60 |
| <b>230</b> | 3040-00-646-6858 | CONNECTING LINK,RIGID         | M-60 |
| <b>231</b> | 3040-00-678-4158 | HUB,BODY                      | M-60 |
| <b>232</b> | 3040-00-678-4294 | SHAFT,SHOULDERED              | M-60 |
| <b>233</b> | 3040-00-776-7849 | LEVER,REMOTE CONTROL          | M-60 |
| <b>234</b> | 3040-00-851-5001 | HOUSING ASSEMBLY, RO , NO 1   | M-60 |
| <b>235</b> | 3040-00-851-5005 | HOUSING ASSEMBLY, TO , NO 1   | M-60 |

|            |                  |                                 |      |
|------------|------------------|---------------------------------|------|
| <b>236</b> | 3040-00-921-5204 | SHAFT ASSEMBLY,FLEXIBLE         | M-60 |
| <b>237</b> | 3040-00-963-9053 | CAM,CONTROL                     | M-60 |
| <b>238</b> | 3040-00-980-9293 | CONNECTING LINK,RIGID           | M-60 |
| <b>239</b> | 3040-01-012-4705 | HOUSING,MECHANICAL DRIVE        | M-60 |
| <b>240</b> | 3040-01-018-3702 | SHAFT,STRAIGHT                  | M-60 |
| <b>241</b> | 3040-01-019-7124 | BRACKET,EYE,ROTATING SHAFT      | M-60 |
| <b>242</b> | 3040-01-019-7176 | HOUSING,MECHANICAL DRIVE        | M-60 |
| <b>243</b> | 3040-01-051-1524 | SHAFT ASSEMBLY,                 | M-60 |
| <b>244</b> | 3040-01-054-0265 | FILTER HOUSING                  | M-60 |
| <b>245</b> | 3040-01-062-8265 | HOUSING,MECHANICAL DRIVE        | M-60 |
| <b>246</b> | 3040-01-120-2885 | HOUSING ASSEMBLY                | M-60 |
| <b>247</b> | 3040-01-134-6542 | LINK ASSEMBLY, GREAS , RIGHT    | M-60 |
| <b>248</b> | 3040-01-134-6545 | CYLINDER ASSEMBLY, A , LEFT     | M-60 |
| <b>249</b> | 3040-01-184-4813 | HOUSING,MECHANICAL              | M-60 |
| <b>250</b> | 3120-00-121-0776 | BEARING,SLEEVE                  | M-60 |
| <b>251</b> | 3120-00-533-3378 | BEARING, PLAIN, SELF-           | M-60 |
| <b>252</b> | 3120-01-252-9712 | SPACER, HUB, TRACK SU           | M-60 |
| <b>253</b> | 3130-00-506-1359 | ROLLER, LINEAR-ROTAR            | M-60 |
| <b>254</b> | 3130-00-779-2538 | CAP,PILLOW BLOCK                | M-60 |
| <b>255</b> | 3130-00-779-2541 | CAP,PILLOW BLOCK                | M-60 |
| <b>256</b> | 3130-01-149-5858 | HOUSING,BEARING UNIT            | M-60 |
| <b>257</b> | 4010-00-383-3681 | WIRE ROPE ASSEMBLY,             | M-60 |
| <b>258</b> | 4010-01-218-9955 | CHAIN ASSEMBLY,                 | M-60 |
| <b>259</b> | 4140-00-016-2615 | FAN,CENTRIFUGAL                 | M-60 |
| <b>260</b> | 4140-00-350-9401 | HOUSING CENTRIFUGAL             | M-60 |
| <b>261</b> | 4140-00-442-5895 | BRACKET, MOUNTING, FLYWHEEL END | M-60 |

|            |                  |                            |      |
|------------|------------------|----------------------------|------|
| <b>262</b> | 4140-01-148-6545 | IMPELLER,FAN,AXIAL         | M-60 |
| <b>263</b> | 4140-01-161-8828 | IMPELLER,FAN,AXIAL         | M-60 |
| <b>264</b> | 4210-01-048-6242 | VALVE ASSEMBLY             | M-60 |
| <b>265</b> | 4240-00-807-6856 | HEATER , AIR,ELECTRIC      | M-60 |
| <b>266</b> | 4240-00-828-3952 | FILTER, GAS                | M-60 |
| <b>267</b> | 4240-01-026-3112 | PRECLEANER AND PART        | M-60 |
| <b>268</b> | 4310-00-939-7098 | VACUUM PUMP RECIPRO        | M-60 |
| <b>269</b> | 4320-00-285-3756 | PUMP, INFLATING,           | M-60 |
| <b>270</b> | 4320-00-678-7274 | PUMP,ROTARY                | M-60 |
| <b>271</b> | 4320-00-871-2834 | BILGE (FOR COMPONENT PARTS | M-60 |
| <b>272</b> | 4342-00-080-7552 | DOOR ACCESS                | M-60 |
| <b>273</b> | 4342-00-997-4524 | DOOR ACCESS                | M-60 |
| <b>274</b> | 4370-01-287-1087 | CONNECTOR                  | M-60 |
| <b>275</b> | 4710-00-604-6818 | TUBE ASSEMBLY,METAL        | M-60 |
| <b>276</b> | 4710-00-614-6893 | TUBE ASSEMBLY,METAL        | M-60 |
| <b>277</b> | 4710-00-614-6898 | TUBE ASSEMBLY,METAL        | M-60 |
| <b>278</b> | 4710-00-614-6905 | TUBE ASSEMBLY,METAL        | M-60 |
| <b>279</b> | 4720-00-891-7864 | HOSE ASSEMBLY              | M-60 |
| <b>280</b> | 4720-00-891-7865 | HOSE ASSEMBLY,             | M-60 |
| <b>281</b> | 4720-01-096-9351 | HOSE ASSEMBLY,             | M-60 |
| <b>282</b> | 4720-01-119-7779 | HOSE ASSEMBLY,             | M-60 |
| <b>283</b> | 4730-00-087-2893 | TEE,PIPE TO BOSS           | M-60 |
| <b>284</b> | 4730-00-168-2850 | CONNECTCR PART             | M-60 |
| <b>285</b> | 4730-00-886-5854 | STRAINER ELEMENT,SE        | M-60 |
| <b>286</b> | 4730-00-934-8295 | ADAPTER,STRAIGHT,FL        | M-60 |
| <b>287</b> | 4730-00-934-8296 | ADAPTER,STRAIGHT,FL        | M-60 |

|            |                  |                                                    |      |
|------------|------------------|----------------------------------------------------|------|
| <b>288</b> | 4810-00-933-4113 | VALVE,LINEAR,DIRECTIONAL CONTROL                   | M-60 |
| <b>289</b> | 4810-00-974-7605 | VALVE,SOLENOID                                     | M-60 |
| <b>290</b> | 4910-01-048-8706 | ENGINE AND TRANSMISSION SLING                      | M-60 |
| <b>291</b> | 4910-01-218-5896 | ADJUSTING LINK                                     | M-60 |
| <b>292</b> | 4931-00-087-5105 | AUTO COLLIMATING FI                                | M-60 |
| <b>293</b> | 4931-00-930-9030 | FIXTURE,TELESCOPE TESTING,FIRE CONTROL MAINTENANCE | M-60 |
| <b>294</b> | 4931-00-998-0034 | FIXTURE,TELESCOPE TESTING,FIRE CONTROL MAINTENANCE | M-60 |
| <b>295</b> | 4931-01-019-4551 | ELECTRONIC UNIT,LASER RANGING                      | M-60 |
| <b>296</b> | 4933-00-796-4537 | ROLL ASSEMBLY,TOOL AND GUN                         | M-60 |
| <b>297</b> | 4933-01-305-7272 | COMPRESSOR,GUN RECOIL SPRING                       | M-60 |
| <b>298</b> | 5120-00-034-8445 | REMOVER, FINAL DRIVE,                              | M-60 |
| <b>299</b> | 5120-00-045-4360 | ADAPTER,TORQUE WRENCH                              | M-60 |
| <b>300</b> | 5120-00-181-6813 | SOCKET, SOCKET WRENCH                              | M-60 |
| <b>301</b> | 5120-00-348-8409 | ADAPTER,TORQUE WRENCH                              | M-60 |
| <b>302</b> | 5120-00-570-7486 | TOOL, BRAKE                                        | M-60 |
| <b>303</b> | 5120-00-977-5581 | INSERTER, SEAL,                                    | M-60 |
| <b>304</b> | 5120-01-005-2995 | TEST TOOL,GENERATOR COUPLING TORQUE                | M-60 |
| <b>305</b> | 5120-01-016-2149 | FIXTURE, TRACK CONNE,                              | M-60 |
| <b>306</b> | 5120-01-048-8640 | SOCKET, WRENCH,                                    | M-60 |
| <b>307</b> | 5120-01-050-2070 | WRENCH, BOX,                                       | M-60 |
| <b>308</b> | 5120-01-052-5642 | PULER AND PUMP,                                    | M-60 |
| <b>309</b> | 5120-01-085-2542 | WRENCH,SPANNER                                     | M-60 |
| <b>310</b> | 5120-01-099-6437 | INSERTER AND REMOVER,BEARING AND BUSHING           | M-60 |
| <b>311</b> | 5120-01-100-0391 | WRENCH, SPANNER,                                   | M-60 |
| <b>312</b> | 5120-01-135-0847 | SPANNER ATTACHMENT,                                | M-60 |
| <b>313</b> | 5120-01-135-0993 | SOCKET, SOCKET WRENC                               | M-60 |

|            |                  |                                                 |      |
|------------|------------------|-------------------------------------------------|------|
| <b>314</b> | 5120-01-135-0995 | SOCKET, SOCKET WRENC,                           | M-60 |
| <b>315</b> | 5120-01-135-1058 | WRENCH,RATCHET                                  | M-60 |
| <b>316</b> | 5120-01-135-1059 | HANDLE,SOCKET WRENCH                            | M-60 |
| <b>317</b> | 5180-01-135-4757 | TOOL KIT,VEHICULAR,SPECIAL PURPOSE              | M-60 |
| <b>318</b> | 5180-01-218-2105 | SLIDE                                           | M-60 |
| <b>319</b> | 5305-00-022-4255 | Wedge Bolt                                      | M-60 |
| <b>320</b> | 5305-01-063-1592 | SCREW,EXTERNALLY RELIEVED BODY                  | M-60 |
| <b>321</b> | 5305-01-236-0313 | SCREW,EXTERNALLY RELIEVED BODY                  | M-60 |
| <b>322</b> | 5306-00-706-9543 | BOLT                                            | M-60 |
| <b>323</b> | 5310-00-538-0800 | NUT, PLAIN, ASSEMBLED                           | M-60 |
| <b>324</b> | 5310-01-006-2085 | Guide Nut                                       | M-60 |
| <b>325</b> | 5310-01-102-2711 | Pad Nut                                         | M-60 |
| <b>326</b> | 5310-01-159-0063 | WASHER,FLAT                                     | M-60 |
| <b>327</b> | 5315-00-706-9195 | PIN, GROOVED,                                   | M-60 |
| <b>328</b> | 5330-00-169-1785 | PARTS KIT,SEAL REPLACEMENT,MECHANICAL EQUIPMENT | M-60 |
| <b>329</b> | 5330-01-019-7148 | RETAINER SLEEVE,SEAL                            | M-60 |
| <b>330</b> | 5330-01-161-8806 | GASKET                                          | M-60 |
| <b>331</b> | 5330-01-470-2228 | GASKET                                          | M-60 |
| <b>332</b> | 5340-00-065-0743 | CONNECTING LINK,                                | M-60 |
| <b>333</b> | 5340-00-133-9567 | BRACKET, MOUNTING                               | M-60 |
| <b>334</b> | 5340-00-133-9580 | BRACKET, MOUNTING                               | M-60 |
| <b>335</b> | 5340-00-226-2658 | BRACKET, MOUNTING, RIGHT FRONT                  | M-60 |
| <b>336</b> | 5340-00-525-8188 | COVER,ACCESS                                    | M-60 |
| <b>337</b> | 5340-00-566-3844 | LEVER,MANUAL CONTROL                            | M-60 |
| <b>338</b> | 5340-00-675-0475 | LEVER,MANUAL CONTROL                            | M-60 |
| <b>339</b> | 5340-00-678-3025 | COVER,ACCESS                                    | M-60 |

|            |                  |                              |      |
|------------|------------------|------------------------------|------|
| <b>340</b> | 5340-00-678-3026 | COVER,ACCESS                 | M-60 |
| <b>341</b> | 5340-00-678-3030 | COVER,ACCESS                 | M-60 |
| <b>342</b> | 5340-00-699-9049 | COVER,ACCESS                 | M-60 |
| <b>343</b> | 5340-00-705-8039 | COVER, ACCESS                | M-60 |
| <b>344</b> | 5340-00-723-7771 | PLUNGER,DETENT               | M-60 |
| <b>345</b> | 5340-00-792-8123 | BRACKET, MOUNTING            | M-60 |
| <b>346</b> | 5340-00-834-5906 | COVER,ACCESS                 | M-60 |
| <b>347</b> | 5340-00-886-1205 | HANDLE,MANUAL CONTROL        | M-60 |
| <b>348</b> | 5340-00-927-3305 | COVER, ACCESS ,              | M-60 |
| <b>349</b> | 5340-00-937-1521 | BRACKET, SHIFT CONTR         | M-60 |
| <b>350</b> | 5340-00-937-2486 | SHAFT, SHOULDERED            | M-60 |
| <b>351</b> | 5340-00-937-2538 | HINGE, TRAVEL LOCK G         | M-60 |
| <b>352</b> | 5340-00-938-1640 | BRACKET ASSEMBLY, SU         | M-60 |
| <b>353</b> | 5340-01-010-1644 | ADAPTER, TORQUE,             | M-60 |
| <b>354</b> | 5340-01-031-0113 | HINGE, ACCESS DOOR           | M-60 |
| <b>355</b> | 5340-01-038-8306 | LEVER, MANUAL CONTRO         | M-60 |
| <b>356</b> | 5340-01-063-0478 | COVER,ACCESS                 | M-60 |
| <b>357</b> | 5340-01-077-1679 | LEVER, MANUAL CONTRO , LEFT  | M-60 |
| <b>358</b> | 5340-01-077-1680 | LEVER, MANUAL CONTRO , RIGHT | M-60 |
| <b>359</b> | 5340-01-099-6425 | GRIP, HANDLE                 | M-60 |
| <b>360</b> | 5340-01-138-7070 | COVER,ACCESS                 | M-60 |
| <b>361</b> | 5340-01-148-6552 | COVER,ACCESS                 | M-60 |
| <b>362</b> | 5340-01-148-6553 | COVER,ACCESS                 | M-60 |
| <b>363</b> | 5340-01-152-2514 | BRACKET,ANGLE                | M-60 |
| <b>364</b> | 5340-01-152-2515 | BRACKET,ANGLE                | M-60 |
| <b>365</b> | 5340-01-152-2541 | COVER, ACCESS ,              | M-60 |

|            |                  |                           |      |
|------------|------------------|---------------------------|------|
| <b>366</b> | 5340-01-152-2542 | COVER, ACCESS ,           | M-60 |
| <b>367</b> | 5340-01-161-8875 | STANDOFF,THREADED,SPACING | M-60 |
| <b>368</b> | 5340-01-170-9949 | BRACKET,MOUNTING          | M-60 |
| <b>369</b> | 5340-01-226-9228 | BRACKET,MOUNTING          | M-60 |
| <b>370</b> | 5340-01-239-6900 | STRAP, RETAINING          | M-60 |
| <b>371</b> | 5340-01-495-4503 | COVER,DUST,ASSY           | M-60 |
| <b>372</b> | 5340-01-499-1700 | BRACKET,MOUNTING          | M-60 |
| <b>373</b> | 5340-01-680-0513 | BRACKET, MOUNTING         | M-60 |
| <b>374</b> | 5342-00-105-6142 | DOOR, ACCESS              | M-60 |
| <b>375</b> | 5342-00-124-7214 | BRACKET ASSEMBLY          | M-60 |
| <b>376</b> | 5342-00-678-6178 | COUPLING, CLAMP,          | M-60 |
| <b>377</b> | 5342-00-837-8789 | DOOR,ACCESS,WEAPON SYSTEM | M-60 |
| <b>378</b> | 5342-00-839-6657 | ARM,HAND CRANK            | M-60 |
| <b>379</b> | 5342-00-891-4049 | BRACKET                   | M-60 |
| <b>380</b> | 5342-01-023-7875 | DOG, DOOR CLOSER          | M-60 |
| <b>381</b> | 5342-01-084-6004 | DIFFUSER CAP ASSEMBLY     | M-60 |
| <b>382</b> | 5342-01-096-9379 | DOOR, ACCESS              | M-60 |
| <b>383</b> | 5342-01-144-4891 | BOX, HANDSET              | M-60 |
| <b>384</b> | 5342-01-309-8254 | BASE,                     | M-60 |
| <b>385</b> | 5360-01-152-5399 | SPRING,SPIRAL,TORSION     | M-60 |
| <b>386</b> | 5365-01-148-6546 | SPACER,SLEEVE             | M-60 |
| <b>387</b> | 5365-01-148-6550 | SPACER,PLATE              | M-60 |
| <b>388</b> | 5365-01-362-1758 | PLUG,MACHINE THREAD       | M-60 |
| <b>389</b> | 5855-01-096-0871 | VIEWER, NIGHT VISION      | M-60 |
| <b>390</b> | 5855-01-396-0258 | COOLER,CRYOGENIC          | M-60 |
| <b>391</b> | 5860-01-019-3419 | REFLECTOR,RESONANT,LASER  | M-60 |

|            |                  |                                              |      |
|------------|------------------|----------------------------------------------|------|
| <b>392</b> | 5895-01-021-0818 | INDICATOR CONTROL SUBASSEMBLY                | M-60 |
| <b>393</b> | 5895-01-021-8994 | CONTROL, CONVERTER                           | M-60 |
| <b>394</b> | 5895-01-022-2470 | PANEL, INDICATOR                             | M-60 |
| <b>395</b> | 5905-00-235-4467 | RESISTOR, THERMAL                            | M-60 |
| <b>396</b> | 5905-00-368-8387 | RESISTOR, VARIABLE, WIRE WOUND, NONPRECISION | M-60 |
| <b>397</b> | 5905-00-933-9206 | RESISTOR, VARIABLE,                          | M-60 |
| <b>398</b> | 5930-00-126-2470 | SWITCH, LEAD ASSEMBL                         | M-60 |
| <b>399</b> | 5930-00-133-9629 | SWITCH, ENGINE                               | M-60 |
| <b>400</b> | 5930-00-296-6319 | SWITCH, TOGGLE                               | M-60 |
| <b>401</b> | 5930-00-692-4996 | HOUSING, SENSITIVE SWITCH                    | M-60 |
| <b>402</b> | 5930-00-937-2492 | GUARD ASSEMBLY, CONT                         | M-60 |
| <b>403</b> | 5930-01-010-3283 | SWITCH SUBASSEMBLY                           | M-60 |
| <b>404</b> | 5930-01-019-7226 | SWITCH, PUSH                                 | M-60 |
| <b>405</b> | 5930-01-152-2385 | SWITCH, PRESSURE                             | M-60 |
| <b>406</b> | 5930-01-214-6344 | SWITCH, PUSH                                 | M-60 |
| <b>407</b> | 5935-01-006-0618 | CONNECTOR ASSEMBLY, ELECTRICAL               | M-60 |
| <b>408</b> | 5935-01-282-6062 | DUMMY CONNECTOR, PLUG                        | M-60 |
| <b>409</b> | 5940-00-235-7454 | TERMINAL, FEEDTHRU                           | M-60 |
| <b>410</b> | 5945-00-083-0266 | RELAY AND HOUSING A                          | M-60 |
| <b>411</b> | 5945-00-690-2707 | RELAY, ELECTROMAGNET                         | M-60 |
| <b>412</b> | 5945-00-729-7813 | RELAY, ELECTROMAGNET                         | M-60 |
| <b>413</b> | 5945-01-015-2954 | RELAY                                        | M-60 |
| <b>414</b> | 5961-01-037-0687 | SEMICONDUCTOR DEVICE, DIODE                  | M-60 |
| <b>415</b> | 5961-01-088-9404 | SEMICONDUCTOR DEVICE ASSEMBLY                | M-60 |
| <b>416</b> | 5975-01-016-8263 | CASE, SWITCH BOX                             | M-60 |
| <b>417</b> | 5975-01-018-9971 | HANGER, CABLE                                | M-60 |

|            |                  |                                |      |
|------------|------------------|--------------------------------|------|
| <b>418</b> | 5977-01-159-8005 | BRUSH,ELECTRICAL CONTACT       | M-60 |
| <b>419</b> | 5995-00-071-4483 | WIRING HARNESS                 | M-60 |
| <b>420</b> | 5995-00-168-2691 | WIRING HARNESS                 | M-60 |
| <b>421</b> | 5995-00-455-1376 | WIRING HARNESS,                | M-60 |
| <b>422</b> | 5995-00-604-7168 | WIRING HARNESS,                | M-60 |
| <b>423</b> | 5995-00-606-2342 | WIRING HARNESS,                | M-60 |
| <b>424</b> | 5995-00-606-2376 | WIRING HARNESS,                | M-60 |
| <b>425</b> | 5995-00-610-0379 | CABLE ASSEMBLY,                | M-60 |
| <b>426</b> | 5995-00-628-1157 | WIRING HARNESS,                | M-60 |
| <b>427</b> | 5995-00-886-1216 | WIRING HARNESS,BRANCHED        | M-60 |
| <b>428</b> | 5995-01-152-2559 | WIRING HARNESS,                | M-60 |
| <b>429</b> | 5998-00-457-9464 | ELECTRONIC COMPONENTS ASSEMBLY | M-60 |
| <b>430</b> | 5998-00-457-9471 | ELECTRONIC COMPONENTS ASSEMBLY | M-60 |
| <b>431</b> | 5998-01-018-9168 | ELECTRONIC COMPONENTS ASSEMBLY | M-60 |
| <b>432</b> | 5998-01-130-1737 | ELECTRONIC COMPONENTS ASSEMBLY | M-60 |
| <b>433</b> | 5999-00-678-4271 | CONTACT,ELECTRICAL             | M-60 |
| <b>434</b> | 5999-01-016-2270 | CONTACT,ELECTRICAL             | M-60 |
| <b>435</b> | 5999-01-052-1069 | STRIP,ELECTRICAL GROUNDING     | M-60 |
| <b>436</b> | 5999-01-233-0491 | CONTACT,ELECTRICAL             | M-60 |
| <b>437</b> | 6105-00-772-7524 | MOTOR,DIRECT CURREN            | M-60 |
| <b>438</b> | 6105-01-014-4669 | MOTOR,DIRECT CURRENT           | M-60 |
| <b>439</b> | 6105-01-092-1484 | MOTOR,DIRECT CURREN            | M-60 |
| <b>440</b> | 6105-01-159-8004 | STATOR,MOTOR                   | M-60 |
| <b>441</b> | 6110-01-492-2692 | PANEL ASSEMBLY                 | M-60 |
| <b>442</b> | 6130-00-732-4257 | POWER SUPPLY                   | M-60 |
| <b>443</b> | 6130-01-006-0619 | POWER SUPPLY                   | M-60 |

|            |                  |                        |      |
|------------|------------------|------------------------|------|
| <b>444</b> | 6130-01-059-8344 | POWER SUPPLY           | M-60 |
| <b>445</b> | 6140-00-446-9498 | BATTERY                | M-60 |
| <b>446</b> | 6140-01-446-9498 | BATTERY, STORAGE       | M-60 |
| <b>447</b> | 6150-00-123-7381 | CABLE ASSEMBLY,        | M-60 |
| <b>448</b> | 6150-00-606-2353 | WIRING HARNESS         | M-60 |
| <b>449</b> | 6150-00-606-2357 | WIRING HARNESS         | M-60 |
| <b>450</b> | 6150-00-610-0374 | WIRING HARNESS         | M-60 |
| <b>451</b> | 6150-00-628-1160 | CABLE ASSEMBLY,        | M-60 |
| <b>452</b> | 6150-00-674-8738 | LEAD, ELECTRICAL       | M-60 |
| <b>453</b> | 6150-00-678-4224 | CABLE AND CONNECTOR    | M-60 |
| <b>454</b> | 6150-00-707-3949 | CABLE AND ADAPTER LEFT | M-60 |
| <b>455</b> | 6150-00-923-4247 | CABLE ASSEMBLY,        | M-60 |
| <b>456</b> | 6150-00-927-3311 | CABLE ASSEMBLY, POWER  | M-60 |
| <b>457</b> | 6150-00-974-9200 | CABLE ASSEMBLY         | M-60 |
| <b>458</b> | 6150-00-979-6543 | CABLE ASSEMBLY, ELEC   | M-60 |
| <b>459</b> | 6150-01-032-7408 | WIRING HARNESS,        | M-60 |
| <b>460</b> | 6150-01-076-9375 | CABLE ASSEMBLY,        | M-60 |
| <b>461</b> | 6150-01-076-9376 | CABLE ASSEMBLY,        | M-60 |
| <b>462</b> | 6150-01-096-9381 | CABLE ASSEMBLY,        | M-60 |
| <b>463</b> | 6150-01-152-2412 | WIRING HARNESS         | M-60 |
| <b>464</b> | 6150-01-172-7888 | CABLE ASSEMBLY,        | M-60 |
| <b>465</b> | 6160-00-168-2565 | BATTERY BOX            | M-60 |
| <b>466</b> | 6220-00-047-4097 | HEADLIGHT ASSEMBLY     | M-60 |
| <b>467</b> | 6220-00-337-6471 | STOP LIGHT-TAILLIGHT   | M-60 |
| <b>468</b> | 6220-00-337-7463 | DOME LIGHT COMPONENTS  | M-60 |
| <b>469</b> | 6220-00-669-5623 | STOP LIGHT-TAILLIGHT   | M-60 |

|            |                  |                                          |      |
|------------|------------------|------------------------------------------|------|
| <b>470</b> | 6250-00-123-0429 | BASE, LAMPHOLDER                         | M-60 |
| <b>471</b> | 6250-00-978-7337 | BASE ASSEMBLY, INDIC                     | M-60 |
| <b>472</b> | 6515-01-611-5925 | TOOL BOX, PORTABLE,                      | M-60 |
| <b>473</b> | 6625-01-019-4540 | PROBE SUBASSEMBLY                        | M-60 |
| <b>474</b> | 6625-01-144-4846 | TEST SET, ELECTRONIC                     | M-60 |
| <b>475</b> | 6650-00-991-8436 | PRISM,OPTICAL INSTRUMENT,MOUNTED         | M-60 |
| <b>476</b> | 6650-00-992-1873 | PRISM,OPTICAL INSTRUMENT,MOUNTED         | M-60 |
| <b>477</b> | 6650-01-019-0005 | MIRROR,OPTICAL INSTRUMENT                | M-60 |
| <b>478</b> | 6650-01-019-3441 | BEAM SPLITTER,OPTICAL INSTRUMENT,MOUNTED | M-60 |
| <b>479</b> | 6650-01-056-2907 | MIRROR,OPTICAL INSTRUMENT                | M-60 |
| <b>480</b> | 6680-00-715-7600 | TRANSMITTER,LIQUID                       | M-60 |
| <b>481</b> | 6680-01-224-7467 | GAGE ROD-CAP,LIQUID LEVEL                | M-60 |
| <b>482</b> | 7953S33          | HOUSING , ROAD WHEEL , NO 2              | M-60 |
| <b>483</b> | 7S53877          | HOUSING, TORSION BAR , NO 2 THRU         | M-60 |
| <b>484</b> | 8140-00-113-9605 | COVER,BOX,ACCESSORIES STOWAGE            | M-60 |
| <b>485</b> | 8140-01-033-2175 | BOX,AMMUNITION                           | M-60 |
| <b>486</b> | 8140-01-033-2176 | BOX,AMMUNITION                           | M-60 |
| <b>487</b> | 8140-01-033-2177 | BOX,AMMUNITION                           | M-60 |
| <b>488</b> | 8145-00-695-9008 | SHIPPING AND STORAG                      | M-60 |
| <b>489</b> | 8145-00-856-8147 | ENGINE AND CONTAINER                     | M-60 |
| <b>490</b> | 8763G16          | HUB, WHEEL, VEHICULAR                    | M-60 |
| <b>491</b> | 9905-01-092-7887 | PLATE,IDENTIFICATION                     | M-60 |
| <b>492</b> | M13486-3         | WIRE, ELECTRICAL                         | M-60 |
| <b>493</b> | PIN11615320      | CONNECTOR                                | M-60 |